



SPLASH HOOP® PRO



Splash Hoop® Pro Assembly Instructions:


1. With the **Backboard** face up on a flat surface, position the **Rim and Net Assembly** and the **Rim Bracket** (as shown) so that the **3 holes** on the **Rim Bracket** **line up** with the **Backboard** holes. Ensure the net is not caught between the **Rim Bracket** and the **Backboard**.

1.




2. Assemble the 3 items beginning with the **2 Long Screws**. Insert the **Long Screws** through the top holes of the **Rim Bracket**, **Rim and Net Assembly**, and finally the **Backboard**. Next, insert the **single Short Screw** through the single bottom hole of the **Rim Bracket**, **Rim and Net Assembly** and then through the **Backboard**. Use the provided **Allen Wrench** to securely tighten each screw.

2.




assembly continued on back →

3. Insert the white **Stand** through the bottom hole of the **Base** with the Stand facing forward. Ensure both parts are firmly secured (they will be tighter once the base is filled with water).




4. Before filling the **Base** with water, place the **Base** in the desired play area as it will be difficult to move once filled. Once the **Base** is filled, seal it with the **Base Fill Cap**.



⚠ Only fill with water

5. Finally, slide the **Backboard** onto the white **Stand** and firmly press down to ensure it is secured into place. No tools or screws are required.



6. Pump up the basketballs with the included pump and you are now ready to enjoy your Splash Hoop® Pro!

Care Instructions:

- Never hang or dunk on the rim.
- The plastics used are UV treated to increase their resistance to fading, but they will eventually fade if left out in direct sunlight. This should not affect gameplay.
- To prolong the products lifespan, we recommend storing the Splash Hoop® Pro and all accessories indoors when not in use. Ensure the base is drained and all parts are dry before storing.
- Store the basketballs indoors when not in use, as leaving them in the water or sun will rapidly fade the colors.

WARNING SPLASH HOOP® PRO IS NOT A FLOTATION OR LIFE SAVING DEVICE. SPLASH HOOP® PRO SHOULD BE PLACED AT THE EDGE OF THE POOL, BUT WHERE IT WILL NOT FALL INTO THE POOL. NEVER JUMP, CLIMB, OR HANG ON THE SPLASH HOOP® PRO AS THIS MAY CAUSE THE SPLASH HOOP® PRO TO FALL INTO THE POOL OR ONTO A PLAYER, WHICH MAY CAUSE INJURY. IF SPLASH HOOP® PRO FALLS INTO THE POOL, IMMEDIATELY NOTIFY AN ADULT TO SAFELY RETRIEVE IT. ALWAYS OBSERVE ALL POOL AND WATER SAFETY RULES. ALWAYS USE SPLASH HOOP® PRO ONLY AS INTENDED AND WITH COMPETENT ADULT SUPERVISION. ONLY USE WITH INCLUDED BALLS. INSPECT SPLASH HOOP® PRO BEFORE USE, AND IMMEDIATELY CEASE USE IF ANY PARTS ARE DAMAGED. ONLY FILL BASES WITH WATER, AND NEVER FILL WITH SAND.

Customer Service:

If you have any questions or concerns regarding your GoSports® Splash Hoop® Pro, please reach out to us at info@PlayGoSports.com and we will get back to you right away. We stand behind our products 100% and want to make sure you get the full enjoyment that you paid for.