










# ASSEMBLY INSTRUCTION

## ARMLESS CHAIR

LEGS, HARDWARE, BACK CUSHION, PILLOW, HEADREST ARE STORED IN THE BOTTOM OF THE SEAT, PLEASE TAKE OUT FOR ASSEMBLY.

| NO. | PARTS LIST   | QTY | DESCRIPTION  |
|-----|--|-----|--------------|
| A   |                     | 1   | Seat Frame   |
| B   |                     | 1   | Seat Cushion |
| C   |                     | 1   | Headrest     |
| D   | <br>40"*17-1/2"     | 1   | Back Cushion |
| E   | <br>27-1/4"*15-1/4" | 1   | Pillow       |
| F   | <br>Ø3-1/8"*5-1/8"  | 4   | Wooden Leg   |
| G   |                     | 4   | Washer       |
| H   |                    | 2   | Connector    |


### STEP 1:




# ASSEMBLY INSTRUCTION

## ARMLESS CHAIR

### STEP 2:



### STEP 3 (Completed) :



### CARE INSTRUCTION FOR FABRIC FURNITURE




In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures.

°Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/damage fabric.


°Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.

# ASSEMBLY INSTRUCTION

## ARMLESS CHAIR

| NO. | PARTS LIST  | QTY | DESCRIPTION   |
|-----|---|-----|---------------|
| A   |  | 2   | ARMLESS CHAIR |
| B   |  | 2   | CORNER SEAT   |
| C   |  | 1   | OTTOMAN       |

STEP 1 :



STEP 2 (Completed) :

