

B1&B2

KITCHEN ISLAND

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS :

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to ensure fast & easy assembly.



Warning !




- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

| | | | |
|----|---|----------------------|------|
| AV |  | KITCHEN CART BASE | 1PC |
| BV |  | KITCHEN CART TOP | 1PC |
| CV |  | LEG | 4PCS |


HARDWARE IDENTIFICATION

Z-B2(BOX 2) - HARDWARE PACK


| | | | |
|---|---|--------------|------|
| 1 |  | ALLEN WRENCH | 1PC |
| 2 |  | BOLT | 4PCS |
| 3 |  | LOCK WASHER | 4PCS |
| 4 |  | FLAT WASHER | 4PCS |
| 5 |  | GLUE | 1PC |
| 6 |  | WOOD PLUG | 4PCS |

NOTE : PHILLIPS HEAD SCREW DRIVER IS REQUIRED IN THE ASSEMBLY PROCESS. HOWEVER, MANUFACTURER DOES NOT PROVIDE THIS ITEM.


STEP 1




STEP 2




STEP 3





STEP 4



STEP 4.1




STEP 4.2



STEP 5

Close the kitchen cart top



STEP 6

Open up the kitchen cart top

