


Assembly Instructions




Hardware Components

This bag contains small parts that present a choking hazard for children under 3 years of age. These parts are for adult assembly only and should be permanently affixed to the furniture. Any unused parts should be discarded properly.





X4
1/4-20 Wing Nut




X4
1/4-20 x 1 3/4

Step 1



Step 2



Step 3

