

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

710977
END TABLE

ITEM:710977

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION







A	LEFT SIDE PANEL		1 PC	H	TOP PANEL		1 PC
B	RIGHT SIDE PANEL		1 PC	I	DRAWER FRONT PANEL		1 PC
C	LONG DECORATIVE STRIP		2 PCS	J	DRAWER BACK PANEL		1 PC
D	SHORT DECORATIVE STRIP		2 PCS	K	LEFT DRAWER SIDE PANEL		1 PC
E	BOTTOM PANEL		1 PC	L	RIGHT DRAWER SIDE PANEL		1 PC
F	CROSS PANEL		1 PC	M	DRAWER BOTTOM PANEL		1 PC
G	BACK PARTITION PANEL		1 PC				

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:710977

HARDWARE IDENTIFICATION**Z**

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	7	HANDLE L= 120mm SR		1 PC
2	WOODEN DOWEL Ø8x30mm		16 PCS	8	HINGE SCREW Ø4x15mm SR		2 PCS
3	CAM BOLT Ø7x35.5mm SR		10 PCS	9	RAIL L = 400mm BLK		2 PCS
4	CAM LOCK Ø15x12mm SR		10 PCS	10	RAIL SCREW Ø3.5x15mm BLK		10 PCS
5	SCREW Ø4.5x42mm SR		16 PCS	11	STICKER Ø20mm		2 PCS
6	SCREW Ø 4.3x35mm SR		4 PCS				








Z7, Z9 not included in blister packaging.**NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: 710977

STEP 1


COASTER
FINE FURNITURE



INCORRECT
CORRECT











Apply glue on all wooden dowels to ensure integrity of the structure.




ITEM: 710977

STEP 2


COASTER
FINE FURNITURE



INCORRECT
CORRECT




Apply glue on all wooden dowels to ensure integrity of the structure.




ITEM: 710977

STEP 3






STEP 4





ITEM: 710977

COASTER
FINE FURNITURE

STEP 5





STEP 6






ITEM: **710977**

STEP 7

COASTER
FINE FURNITURE




STEP 8



ITEM: 710977


STEP 9





ITEM: **710977**

STEP 10

COASTER
FINE FURNITURE






STEP 11




ITEM: **710977**

STEP 12

COMPLETE



ITEM: 710977



Note : Dimension tolerance $\pm 5\%$