





W3871P476527

W3871P476541

Installation instruction



Note: Due to a printing error, the paper manual has a different SKU from the electronic version. We apologize for the inconvenience. The electronic manual contains the correct SKU.

 2PERS	 60 MIN	<u>Tool Required Not Provided</u> 
--	--	--



[EN]

Warning: Please read instructions fully before starting assembly. Check you have all the components and tools listed on pages.

Warning: Please place all parts on a flat surface. Place a soft blanket or similar underneath to protect against scratches or stains. Avoid dragging or sliding components across the floor.


Warning: Regularly check all fittings and fastenings to ensure they are secure and to prevent accidents. If any parts are missing, broken, damaged, or worn, discontinue use of the product until repairs have been made using factory authorized parts.

Warning: Do not allow children to climb on the furniture as this may result in tipping and serious personal injury. Assemble the furniture away from the reach of children.


Warning: Do not place furniture close to fire sources or high-temperature objects to avoid the risk of fire **Warning:**

Clean furniture with a damp cloth or alcohol, avoid using cleaning agents containing corrosive chemicals.


Warning: This product is equipped with an anti-tilt device. Please be sure to install this device to prevent unnecessary injuries caused by tipping.



EN_QUICKFIT: Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.




EN_CAM LOCK: When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.




EN_Quickfit head should be in the centre of the cam lock when the two panels are joined.

Cam lock should be inserted before quickfit.



EN_
Turn cam lock clockwise to tighten.


Parts List



Hardware

A 66pcs 	B 66pcs 	C 30pcs 	D 10pcs 	E 300mm 6sets 	F 5pcs 	G 2sets 	H 96pcs 
I 88pcs 	J 10pcs 	K 24pcs 	L 2pcs 	M 2pcs 	N 1pc 	O 1pc 	

8pcs




2


I



24pcs



6sets




3

B



2pcs





4

B



2pcs





5

B



2pcs





6


B



2pcs



7



8

C




6pcs


D



3pcs



9



10

B





6pcs

D



3pcs





11

B



6pcs





X3

12

B



6pcs



13

B





5pcs

D



2pcs



14

B





5pcs

D



2pcs



15

B





6pcs


I



8pcs




16






EN

Please measure a position 25mm from the edge of the plate for placing Component L, ensuring it is placed in the middle of the plate.




17



X6

18




X6

19

B



12pcs




X3

20

B



12pcs




X3

21


I



12pcs



3sets




X3

22


I





12pcs



3sets



23



24

I






24pcs

K



24pcs



25

G



G1

G2





G4

14*3.5mm


2sets

Warning: This product is equipped with an anti-tilt device. Please be sure to install this device to prevent unnecessary injuries caused by tipping.




26

G




27



EN

The section pointed to by the arrow can be moved forward and backward.



EN:In order to make the product more beautiful,please paste hardware H on the exposed holes.