

Installation Instruction


Installlation Steps



Step 1 Assemble ② to ①, connect 2A to 1A.



step 2



Step 2 Assemble ③ to ②; 3A connect to 2C with 2D、2E, put the pin inside the hole of shaft

Step 4 Assemble ⑤ to ④; 5A connect to 4E; 5B connect to 4D; assemble ⑦ to 6D



Step 2

Step 3 Fitting ④ to Step 2 ; 4A connect to 2B; 4I connect to 4H with screw; 6A、6B connect to 4G; 4F connect to 6C with screws; ⑧ connect to 4B、4C with screws



step 2

Step 5 Assemble 6E .6F with screws, put ⑨ on 4J and finish