


ASSEMBLY INSTRUCTIONS

WF326034/ WF326035/ WF326036/ WF326037/ WF326038

PART LISTS BOX1: WF326034

A




LOVESEAT (1 PC)

O



LOVE SEAT CUSHION
BACK (2 PCS)

K



LEG (18 PCS)


L



WHEEL (8 PCS)


PART LISTS BOX 2: WF326035

B



CHAISE (1 PC)

H



LOVE & CHAISE BACK
(4PCS)

J



CORNER CUSHION
BACK (1PC)


M



SCREW M4*30
(32 PCS)


PART LISTS BOX 3: WF326036

D




OTTOMAN (1 PC)

O



CHAISE SEAT
CUSHION BACK
(1PC)

C



CORNER (1 PC)

I



CORNER CUSHION
BACK (1PC)


O



CHAISE SEAT
CUSHION BACK
(1PC)


PART LISTS BOX 5: WF326038

E




ARM (1 PC)

F




CORNER
BACK (1PC)

G




CORNER CHAIR
CUSHION BACK (1PC)

N




CORNER SEAT
CUSHION (1PC)


Step 1





Step 3





Step 4




Step 5




Step 6



Step 7



Step 8



Step 9

