


For longer use

Re-tighten bolts every 6 months by using

the enclosed allen-key.

*Using an electric drill can damage the chair. Please re-tighten bolts manually.



Safety Information



chair, with your back to

the backrest



edge of the chair



chair

Do not use the chair with more than one person



Sit in the center of the Do not sit at the front









Do not place all your weight on only the backrest

INSTRUCTION MANUAL

Model: C-3718-3A1P | C-3718-3A2P

HJ-Customer-Service@outlook.com
(909)637-7665 | (909)637-7593



Package List



	_
\sim	

(A)*1 Backrest

(B)*1 Seat



(F)*2 Bolts

()




(I)*4 Bolts

(J)*1 Wrench


INSTRUCTION MANUAL


C-3718-3A1P C-3718-3A2P

HJ-Customer-Service@outlook.com
(909)637-7665 | (909)637-7593
EST 9:00AM--17:00PM



Assembly Instruction





CAUTION:

* Before using the chair, check to ensure that all bolts are fully tightened.

* Lubricate all parts and tighten all bolts every 6 months or whenever needed.