

## NOTICE

---

\*Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.

\*This item should be assembled on a soft surface to prevent scratching the finish during assembly.

\*This item may require periodic tightening.

\*

## PREPARATION

---

\* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

\* If any part is missing or damaged, do not attempt to assemble the product.

\* Estimated Assembly Time: 1 minutes.


\* **Tools Required for Assembly (included): Allen Key**

## CARE AND MAINTENANCE

---

Store outdoor furniture indoors or cover well when not in use. Dust regularly with small brush or vacuum. Spills should be taken care of immediately before they harden or stain with a slightly damp sponge.

Product Dimensions: 18.9" W x 22.4" D x 35.4" H



**WARNING**



**Weight Capacity : 220 lbs**

**Warning : Do not stand on chair**

**Warning : Do not over torque bolts / screws**

# PREPARATION


\*Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

\*If any part is missing or damaged, do not attempt to assemble the product.

\*Estimated Assembly Time : 1 minutes.

\*Tools Required for Assembly (included): Allen Key

\*



Step 1  
Open the chair Vertical arrows

Step 2 Complete product.