








Important: Please read and understand this manual before any assembly. Before assembling this product, please ensure that all parts are in place. Compare the details with the product display presentation. If you have any questions, don't hesitate to contact us.



Preparations:

1.Prepare the required tools.

Star-head Screwdriver	
Wire-stripping Pliers	
Stepladder	
Electrical Tape	

2.Turn off the switch.

3.Put all the parts in order.

Installation procedure:

1.Twist the hanging plate clockwise and take it off from the ceiling fan light.

2.Tighten the part in a counterclockwise direction to make it firm.

3. a: If the roof is a wood ceiling, install the bracket as shown in picture A . Make sure the bracket is securely secured .

b: If the roof is a concrete ceiling, install the bracket as shown in picture B . Make sure the bracket is securely secured .

4.Hook one end of the S-shaped fitting to the light fixture and the other end to the bracket . Just like the picture .

5.a.Connect the black live wire marked "L" on the receiver to the live wire (typically black) on the outlet box.

b.Connect the white neutral wire marked "N" on the receiver to the neutral wire (typically white) on the outlet box.

c.Connect the ground wire (bare wire) from the base of the ceiling fan base with the ground wire (bare wire) of the outlet box.

6. Remove the S-shaped hook and turn the ceiling fan light clockwise on the hanging plate and clamp it tightly according to the bayonet.

7. Tighten the screw . Ensure secure installation .

8. Turn on the switch . The light fixture was successfully installed ! ! !

Specifications

Product Name	Ceiling Fan Light	Item Size	19in*5.7in
Input Voltage	90V-260V	LED	30-60W
Dimensions	10*10ft-13*13ft	Valid Remote Distance	10M
Battery Type	AAA*2	Rotating Speed(rpm)	503-853r/min
Reversible	Yes	Fan Timing	1H/2H