







































PRODUCT PARTS:


A	B	C	D	E	F
					
2PCS	1PC	1PC	1PC	1PC	1PC
G	H	I	J	K	L
					
1PC	1PC	2PCS	1PC	2PCS	2PCS
M	N	O	P	Q	R
					
1PC	1PC	2PCS	2PCS	1PC	1PC
S	T	U	V	W	X
					
1PC	1PC	1PC	1PC	1PC	1PC

HARDWARE:

①	②	③	④	⑤	⑥
 Ø4x12mm		 Ø8x30mm	 1/4"x25mm	 Ø4x25mm	 Ø3x12mm
40+2 PCS	4PCS	24+2 PCS	27+2 PCS	28+2 PCS	14+2 PCS
⑦	⑧	⑨	⑩		
	 5/32"x12mm	 5/32"x18mm			
4PCS	8PCS	4PCS	2PCS		


STEP 1

- ①  8pcs
Ø4x12mm
- ②  4pcs





STEP 2

- ③  4pcs
Ø8x30mm





STEP 3

③  4pcs
Ø8x30mm





STEP 4

③  4pcs
Ø8x30mm





STEP 5

③  6pcs
Ø8x30mm




STEP 6

③  6pcs
Ø8x30mm




STEP 7

④ 1/4"x25mm 3pcs




STEP 8

④ 1/4"x25mm 24pcs





STEP 9

①  8pcs
Ø4x12mm




STEP 10

⑥  14pcs
Ø3x12mm




STEP 11

⑤  8pcs
Ø4x25





STEP 12





STEP 13

⑤  6pcs
Ø4x25




STEP 14

⑤  8pcs
Ø4x25





STEP 15





STEP 16

5  6pcs
Ø4x25



STEP 17

- ①  8pcs Ø4x12mm
- ⑦  4pcs





STEP 18

- ①  16pcs Ø4x12mm




Three-way adjustable hinge for perfectly aligned doors

1. TO ADJUST DOOR FORWARD OR BACKWARD.
2. TO ADJUST DOOR TO RIGHT OR TO LEFT.
3. TO ADJUST DOOR UP OR DOWN.






STEP 19

⑧  8pcs
5/32"x12mm




STEP 20

⑨  4pcs 5/32"x18mm
⑩  2pcs



STEP 21



To install the Top (1) to the vanity (2). Apply silicone caulk to the top edge of the wood cabinet. With the help of another adult, gently lower the Sink top with assembled sink onto the cabinet. Make sure the Sink top is flush with the back side of the wood cabinet and the wood cabinet left and right side walls.

STEP 22

