


















# INSTRUCTION

## PARTS LIST

A	B	C	D	E	F	G
						 x8
				<b>K</b>		 x14
				x5		

## ASSEMBLY STEPS

- 

The bracket of the backrest should be above the switch (part C).
- 
- 
- 
- 
- 
- 
- 