





Christmastree

INSTRUCTION MANUAL

Hello! Please read these important attentions...


Please put a thick carpet on the ground to protect the furniture finish and corners. During the installation process, **DON' T** fasten screws tight 100% at a time.

Assembly Instructions

NUMBER	COMPONENT	QUANTITY
Bottom Section A		1PC
Middle Section B1		1PC
Middle Section B2		1PC only for 8FT
Top Section C		1PC
Stand		1PC
Bolt		1PC

Assembly Instructions

①












Contents:

Your tree will come with the following components:

- Tree Top (Section A)
- Middle Body (Section B)
- Middle Body (Section B1, only for 8FT)
- Lower Body (Section C)
- Metal Stand (D)
- Screw*3 (E)

Assembly Instructions



Shaping Instruction

How to fluff the branches

Shaping the tree branches is the last step of assembly. The care and attention given to this final process will result in a genuinely beautiful and appealing holiday centerpiece.


Assembly Instructions



Every tree style is shipped from the factory with the tips of each branch compressed to the center(Fig.1).






Each branch tip must be shaped to it's proper position to give the tree natural look. Spread tips away from the branch gently(Fig.2).



Each individual tip should then be spread out separately. Tips should then be bent slightly upward to add a more natural looking appearance(Fig.3).

Fig.3 shows a typical tree branch after shaping. Branch tips should be carefully pressed back toward center tip when trees are disassembled for storage in original carton.

HARDWARE



NOTE: Please remove the circular protector caps on the end of each pole before assembling.
If the caps were broken, it will not affect the use of

CAUTION

- Firmly secure all screws before use.
- Product is intended for indoor use only.
- Do not place this tree in a wet location.
- This seasonal product is not intended for permanent installation or use.
- Do not use or store this item in the proximity of open flame, flammable/combustible chemicals, or other strong heat sources.



FORM FOR REPLACING MISSING OR DAMAGED PIECES.

Please email to : customerservice@directwicker.com

Model # of product : _____
Ordered by: _____
Ordered No: _____
Delivery date: _____

Were the boxes good when delivery to you Yes / No
Upon receiving the product,were all the parts intact Yes / No

Name: _____
Address: _____

Tel: _____

**If the product is found damaged after assembly, please provide
photo of the entire furniture set and all damaged areas.**

Part#	Qty	Description	Missing/Damaged
			M / D
			M / D
			M / D
			M / D

**If you do not receive a notification of the replacement parts within 1 week,
please email us at customerservice@directwicker.com.**



Customer Instruction Card

To our most beloved and valued customer:

Thank you for your order, and we appreciate your trust and support.

If you need any assistance or have any questions about your order, please reach our customer service team with your order number at:

Direct Wicker Corp Tel:(813)-304-1389

ET: 9 AM - 5 PM, Monday- Friday

If you would like to know more about Direct Wicker or need to forward documents, you can also reach us at: **customerservice@directwicker.com**


Our team will always be here to help.

Common Questions:

1. Normally the cushion is placed within the ottoman/ chair, please turn it upside down, you may find the cushion.
2. Please do not fully tighten the screws before all parts were assembled successfully, in case the products can not be lined up in position.
3. Furniture sets are mostly delivered in multiple cartons. If the numbers of boxes you received are not correct/missing. Please contact us via phone or email with your order number.
4. Our cushions are considered as shower proof, and we recommend that when the furniture set is not in use , cover it with a furniture cover or store it in dry place.
5. Always be careful when cleaning or handling glass (Always wear gloves and read the instructions of any household cleaner.) We do not advise placing hot objects such as tea or coffee pots directly onto the surface of the glass, always use coasters.
6. If you would like to return the order, be sure to also return any accessories and packing slips that came with your original package.
7. For all your accessory needs, please visit our brand's official website: **directwicker.com**.
8. To preserve the longevity and beauty of your glass-topped wicker table, we recommend placing it in a shaded area away from direct sunlight. Additionally, please use a rain cover to protect it when not in use.

Thank you for your understanding and cooperation, we wish you a fantastic shopping experience with us, and we are looking forward to serving you again!

Direct Wicker Team



Your Home Our Passion



For more information, please visit our website:

www.directwicker.com