




Installation & Assembly



**PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION
WHEN YOU USE POWER TOOLS !**


CAUTION:When tightening the screws,tighten sequentially.Do not tighten any screws fully and then towards the next one.When every part is OK, then tighten all the screws.



**PLEASE BE CAREFUL DO NOT DAMAGE THE
HOLE POSITION WHEN YOU USE POWER TOOLS !**


If there are any missing parts, please contact us and we will send you the corresponding replacement part. We also offer an exclusive one-month service where we provide product replacements without the need for repairs, as long as the damage is not caused by human error.

EXPLODED DRAWING




PARTS


① x1




② x1




③ x1




④ x1




⑤ x1




⑥ x1




⑦ x1




⑧ x1




⑨ x2




⑩ x2




⑪ x2




⑫ x2



⑬ x2




⑭ x2



Accessory List

Ax26(+1)



Ø6x35mm

Bx26(+1)



Ø15x10mm

Cx28(+1)




Ø6x30mm

Dx8(+2)




Ø4x35mm

Ex4



Fx4




Gx48(+3)



Ø3x12mm

Hx4



Ix4



Jx4




Ø6x60mm

Kx4



Ø10x10mm

Lx8




Mx8




Ø3x16mm

Nx2





SPECIAL TIPS FOR FITTING CAM-LOCKS AND QUICKFIT

WHEN FITTING CAMLOCK
ENSURE STARTING POSITION IS CORRECT
BEFORE YOU INSERT CONNECTING QUICKFIT
TURN CLOCKWISE UNTIL SECURE




CAM-LOCK







Quickfit head needs to be in centre

QUICKFIT





Tighten until shoulder is flush with panel. DO not overtighten or undertighten (see example below)






1







2




3




4






5





6






7






8 X2





9 X2







10




11




12






13








14




15




16







17 X2




18 X2







If the TV cabinet is unstable with the ground, please rotate the 13 # adjusting foot pad (N).



AFTER-SALE SERVICE

If you have any suggestions for our products or find that the products have quality problems, please contact us first, our after-sales team will reply you within 24 hours, and we will do our best to give you solutions until you are satisfied.

Guaranteed Customer Service

Your shopping experience is very important to us!
Feel unsatisfied? **Contact us!**
Have any questions? **Contact us!**

Wanna share your experience with our products?
Share your pictures with us.

Any suggestions? **Contact us!**
We gotcha back!