


Assembly Instruction Sheet for Model 371026

Package Contents

Part	Description	Quantity
A	Lamp Socket	1 pc.
B	Metal Shade	1 pc.
C	Pulley Assembly	1 pc.
D	Ceiling Canopy	1 pc.



STEP 1

Remove the socket ring from Lamp Socket(A).
Place the Metal Shade(B) to the Socket(A).
Screw the socket ring back to Socket(A) to stabilize the Shade(B).

STEP 2

Thread the cord through the slide tube assembly on Pulley Assembly(C). And feed the cord through the pulley on Ceiling Canopy(D) and Pulley Assembly(C). Attach the cord to the Ceiling Canopy(D) with cord grip.

STEP 3

Remove the mounting bracket from Ceiling Canopy(D).

STEP 4

Mark the drilling position on ceiling with the help of the mounting bracket. Drill holes on the marks and stick the expansion anchors into the holes. Fix the mounting bracket to the expansion anchors with self-tapping screws.

STEP 5

Hold the fixture close to ceiling.
Connect one supply wire to one of the two wires from the fixture.
Connect the other supply wire to the other wires from the fixture.

STEP 6

Attach the Canopy(D) to the mounting bracket.

STEP 7

Insert your bulb to the bulb base.

Your fixture is now assembled and ready to use.