Assembly Instructions - Please keep for future reference




Table Dimensions	Bench Dimensions
Width- 51inch	Width-16inch
Depth-19.75inch	Depth-12.25inch
Height- 29.75inch	Height-17.5inch

Important - Please read these instructions fully before starting assembly

Issue 1 - 03/2025

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure That all bolts and fittings are tightened properly.

WARNING
In order to help prevent overturning –
please follow these instructions

To help prevent product toppling over please follow the below steps:-









Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Please note that only the anti tip strap is provided.
You will need to provide wall plugs and screws applicable for your wall type


Components - Fittings


Please check you have all the panels listed below

Note: The quantitie below are the correct amount to complete the assembly. In some cases more fittings maybe supplied than are required.

Ⓐ  x30	Ⓑ  x30
Ⓒ  x24	Ⓓ  M3. 5x12mm x45
Ⓔ  M4×35mm x30	Ⓕ  x5
Ⓖ  x1	Ⓗ  x2
Ⓙ  M3x14mm x2	Ⓚ  x2
Ⓛ  x4	Ⓜ  x3
Ⓝ  M4x12mm x38	Ⓞ  x1

Ruler - Use this ruler to help correctlly identify the screws










The screws length is measured from the head to the point (35mm screw shown).


Components - Fittings


Please check you have all the panels listed below

Note: The quantitie below are the correct amount to complete the assembly. In some cases more fittings maybe supplied than are required.

Ⓟ  Ø6X25mm x2	Ⓠ  x2
Ⓡ  x2	Ⓢ  M4x18mm x5
Ⓣ  M3x14mm x12	Ⓤ  x1
Ⓥ  x2	Ⓦ  Ø6X45mm X8
 Screw driver (not provided)	Ⓧ


Ruler - Use this ruler to help correctlly identify the screws



















The screws length is measured from the head to the point (35mm screw shown).















Assembly Instructions






Assembly Instructions

1  1pcs	2  1pcs	3  1pcs
4  1pcs	5  1pcs	6  1pcs
7  1pcs	8  1pcs	9  1pcs
10  1pcs	11  2pcs	12  2pcs
13  2pcs	14  1pcs	15  1pcs

Assembly Instructions


16  1pcs	17  1pcs	18  1pcs
19  1pcs	20  1pcs	21  1pcs
22  1pcs	23  4pcs	24  1pcs
25  3pcs	26  3pcs	27  1pcs
28  1pcs	29  2pcs	30  2pcs

Assembly Instructions

31  2pcs	32  1pcs	33  4pcs
34  2pcs		


Assembly Instructions

Step 1



A	J		G
X6	M3x14mm x2	Screw driver (not provided)	x1


Step 2



D	M	
x8	CL CR x2	Screw driver (not provided)


Assembly Instructions

Step 3



Ⓑ x2	Screw driver (not provided)	Ⓒ x2


Step 4



Ⓑ x2	Screw driver (not provided)	Ⓒ x2


Assembly Instructions

Step 5




Ⓑ	Screw driver (not provided)	Ⓒ
x2		x2


Step 6




Assembly Instructions


Step 7



Ⓔ		Ⓒ
 M4×35mm x6	 Screw driver (not provided)	 x6


Step 8





Ⓛ		Ⓝ
 x4	 Screw driver (not provided)	 M4x12mmx20


Assembly Instructions


Step 9



Ⓐ  x4	 Screw driver (not provided)


Step 10



Ⓑ  x4	 Screw driver (not provided)	Ⓒ  x4


Assembly Instructions

Step 11



D	M	Screw driver (not provided)
x4	x1	


Step 12



A	B	C	Screw driver (not provided)
x4	x4	x4	


Assembly Instructions

Step 13



Ⓔ	Screw driver (not provided)	Ⓒ
M4×35mm x12		x10


Step 14




Ⓚ	Ⓥ	Ⓝ
M4x12mm x2	x2	M4x12mm x10

Assembly Instructions

Step 15




Step 16



Ⓕ x1	Ⓞ x1	Ⓟ Ø6X25mm x2	Ⓢ M4x18mm x1


Assembly Instructions

Step 17



A	D	Q	
x4	M3. 5x12mm x4	x2	Screw driver (not provided)


Step 18




B	C	
x4	x4	Screw driver (not provided)

Assembly Instructions


Step19




If you find that there is a large gap between or beside the door, above or below the door, it's not the product problem, please adjust the hinge according to the diagram as below





Door left and right adjustment by loosening the screws on the mounting plate.



Door in and out adjustment by loosening the screws on the hinge arm.





Door up and down adjustment using the front adjustment screw on the hinge.

Ⓓ	Ⓝ	Ⓡ	
 M3. 5x12mm x8	 M4x12mm x8	 x2	 Screw driver (not provided)

Assembly Instructions


Step 20



T  M3x14mm x12	 Screw driver (not provided)

Assembly Instructions


Step 21



K x2	Screw driver (not provided)


Assembly Instructions


Step 22



D x5	H x2	U x1	Screw driver (not provided)

Step 23






E M4×35mm x12		Screw driver (not provided)


Assembly Instructions

Step 24




A	Screw driver (not provided)
x12	

Step 25




Assembly Instructions

Step 26



B	Screw driver (not provided)
x12	


Step 27



D	M	Screw driver (not provided)
x12	DR CR x3	


Assembly Instructions

Step 28




F x3	S M4x18mm x3	Screw driver (not provided)

Step 29



Assembly Instructions


Step 30



Ⓓ x4	Ⓕ x1	Ⓢ M4x18mm x1	Screw driver (not provided)

Assembly Instructions

Step 31



W	O
Ø6X45mm X8	

Assembly Instructions

Step 32

