

# WONDERFOZD

— OUTDOOR —

## S3 Utility Wagon Instructions



### Features:

- 200 lbs max weight capacity
- One-step folding and unfolding for compact storage and transport
- Adjustable push handle
- Pull handle with spring bounce design
- Built-in 1-step foot brake system
- Rear basket with a removable insulated bag
- Wide all-terrain wheels
- Interior and exterior mesh organization pockets

### How to Clean

- Use damp cloth with mild soap and warm water
- Do not use chemicals

### !WARNING!

- Not suitable for children to ride
- This is NOT a toy

## Wagon Set Up



### Step 1

Disengage front and back wheel brakes by lifting the brake levers.



### Step 2

Pull the side latch to unlock frame.




### Step 3

Spread apart wagon frame until fully Opened. Use with caution to avoid any pinching.



### Step 4

Unlock front latch to release pull handle, then pull the handle up to extend. You will hear a click sound when handle is fully extended.



### Step 5

Adjust Push bar height by pressing the knobs with your thumbs.



### Step 6

Set up is complete!

### Folding the Wagon



#### Step 1

Pull up the center strap to fold the wagon.



#### Step 2

Once the wagon is completely folded, securely lock the side latch and apply the brakes. The wagon is now ready to be stored.