

ASSEMBLY INSTRUCTIONS

MEDIA STAND - ANYWHERE




***** CAUTION ***** - This stand is intended for use only with the products and maximum weights indicated. Use with other products or products heavier than the maximum weights indicated may result in instability causing possible injury.

Model:

Distribution/Manufactory:

Original:

Manufacture Date:



PLASMA / LCD TELEVISION
MAXIMUM SIZE 40 INCH DIAGONAL
MAXIMUM LOAD 200 LBS

PRODUCT WEIGHING
25 POUNDS MAXIMUM

PRODUCT WEIGHING
50 POUNDS MAXIMUM



We are here to help!

We do our best to insure that your furniture arrives in excellent condition. In the event that a part is damaged or missing, we will be happy to provide you with replacement parts, at no charge, within 30 days of purchase, providing the parts are available in our warehouse and the item purchased is part of our current inventory. In order to receive spare parts, at no charge, you must provide proof of purchase within 30 days.

If you need assistance with assembly or replacement parts, please call Service, prior to returning the item to the store.

PARTS IDENTIFICATION

ITEM	DESCRIPTION	QTY
#1	TOP PANEL	01
#2	LEFT SIDE	01
#3	RIGHT SIDE	01
#4	MIDDLE DIVIDER PANEL	01
#5	RAIL	01
#6	UPPER CROSS BAR	01
#7	LOWER CROSS BAR	01
#8	BACK PANEL	01
#9	BOTTOM PANEL	01
#10	ADJUSTABLE SHELF	02
#11	LEG	01
#12	DRAWER FRONT	02
#13	LEFT DRAWER SIDE	02
#14	RIGHT DRAWER SIDE	02
#15	DRAWER BACK	02
#16	DRAWER BOTTOM	02
#17	DRAWER SUPPORT	02



X 2






For ease of identification all parts are labeled to correspond to the Step number in which the part is used.

If any parts are missing or damaged in this package, we will be happy to provide you with replacement parts, at no charge, within 30 days of purchase, providing the parts are available in our warehouse and the item purchased is part of our current inventory. In order to receive spare parts, at no charge, you must provide proof of purchase within 30 days.

Call us toll free or visit our web site to order spare parts and for care instructions on your newly purchased furniture.

HARDWARE IDENTIFICATION

Please line up the hardware with the correct full size image to make sure you are installing the hardware correctly.





ITEM	PICTURE		DESCRIPTION	QTY
A		(Ø8x30mm) Full Size	WOOD DOWEL	22
B		(Ø3.5x25mm) Full Size	SCREW	51
C		(Ø3.5x35mm) Full Size	SCREW	05
D		Not to Scale	HANDLE	02
E		(Ø4x19mm) Full Size	BOLT	04
F		Not to Scale	CAM BOLT	02
G		Not to Scale	CAM LOCK	02
H		Not to Scale	CAM BOLT	02
I		Not to Scale	CAM LOCK	02
J		(Ø7x50mm) Not to Scale	BOLT	02

If any parts are missing or damaged in this package, we will be happy to provide you with replacement parts, at no charge, within 30 days of purchase, providing the parts are available in our warehouse and the item purchased is part of our current inventory. In order to receive spare parts, at no charge, you must provide proof of purchase within 30 days.


Call us toll free or visit our web site to order spare parts and for care instructions on your newly purchased furniture.

HARDWARE IDENTIFICATION


Please line up the hardware with the correct full size image to make sure you are installing the hardware correctly.

ITEM	PICTURE		DESCRIPTION	QTY
K		Not to Scale	PIN	08
L		Not to Scale	STRAP	01
M		(Ø6x18mm) Not to Scale	FLAT WASHER	02
N		Not to Scale	WALL ANCHOR	01
O		(Ø3.5x30mm) Full Size	SCREW	01
P		(Ø3.5x15mm) Full Size	SCREW	01
Q		Not to Scale	ALLEN WRENCH	01

Tools required



Long screwdriver



Short screwdriver




Small hammer


If any parts are missing or damaged in this package, we will be happy to provide you with replacement parts, at no charge, within 30 days of purchase, providing the parts are available in our warehouse and the item purchased is part of our current inventory. In order to receive spare parts, at no charge, you must provide proof of purchase within 30 days.

Call us toll free or visit our web site to order spare parts and for care instructions on your newly purchased furniture.


STEP 1.




STEP 2.




STEP 3.




STEP 4.




STEP 5.




STEP 6.




STEP 7.




STEP 8.




STEP 9.





STEP 10.





STEP 11.





STEP 12.



STEP 13.



STEP 14.



LIMITED 6 MONTHS WARRANTY

WHAT IS COVERED

This product is covered under our manufacturer's 6 months limited warranty. To ensure your complete satisfaction, this warrants to the original purchaser that the supplied item is free from defects in material and workmanship, as of the date of purchase, and that it will, under normal use and proper care, remain so for six months after the date of purchase.

Replacement of missing or initially defective parts will be sent, at no charge, for a period of 30 days from the date of purchase with valid proof of purchase providing the parts are available in our warehouse and the item purchased is part of our current inventory.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from the customer service center. Labor and material charges to remove or replace parts under this warranty are not covered.

This warranty does not cover: Furniture used for commercial purposes, failures caused by improper installation assembly or by improper care, unreasonable or abusive use, freeze damage, acts of God, rust, purchased parts or return freight and packaging charges. Proof of purchase (dated register receipt) is required for warranty claims.

HOW TO OBTAIN SERVICE

For further information, please contact our customer service department