


# WALL ATTACHMENT GUIDE

### WARNINGS!

- This unit is provided with a safety wall strap to prevent accidental tipping. It is important that the strap is correctly fitted. Failure to fit the strap could lead to serious injury.
- \* Never allow children to climb or hang on drawers, doors or shelves.
- \* Place heaviest items in the lower drawers or shelves.
- \* Never open more than one drawer at a time.
- \* From time to time check the fitting to ensure the wall plugs or screws do not become loose.
- \* Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.

#### YOU WILL NEED:







#### HARDWARE:








Screw (to attach strap to product)

Strap and washers

Wall fixings (plugs and screws) are not included please source suitable fixings for your wall type. If in doubt, please consult a qualified tradesperson.







Brick or Masonry Use an appropriate wall plug provided you are sure your wall is sound

Cavity Wall Special toggle wall plugs are needed, seek expert advice

#### Step 1.

Attach strap using screw and washer provided to the product.



## Step 2.

Mark the desired position of the hole on to the wall with a pencil.

Drill and insert suitable screw (not included) for wall through the washer and strap into a wall plug (not included) in the wall.

