




Always Comfortable.™

ASSEMBLY INSTRUCTIONS

Tv Set

So Comfortable,
You'll feel the difference
the moment you sit down.



Should you prefer to
speak with a customer
service representative,
you may call toll free :

1-855-372-2315 U.S. 6am - 5pm PST
0-800-051-6775 U.K. 2pm - 1am GMT

Guidelines

FAILURE TO FOLLOW THESE WARNINGS WHEN IN USE COULD RESULT IN INJURY

- Do not stand on the item or use as a step ladder
- Do not use this item unless all bolts and screws are firmly secured and fastened.
- Check all bolts and screws every 90 days. As necessary tighten if any are loose.
- Lift up then move. Pushing over or dragging this product can result in an injury or cause damage to the floor and outdoor piece.

Pre-Assembly Preparation:


Please read through this instruction booklet before beginning assembly of this item.

Two adults are recommended for assembly.


- Clear out the space for assembly and lay out all parts on Parts List, extra room will allow you to easily determine if all the pieces are present.
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.
- Keep small parts and pieces away from children and pets until fully assembled.
- Please check for any loose screws and tighten them before you use.

WARNING: DO NOT LET
CHILDREN PLAY IN OR
AROUND THE UNIT
DURING ASSEMBLY
DUE TO THE POSSIBLE
RISK OF INJURY.

Parts List



(1) Top Shelf x 1



(2) Shelves x 2



(3) Leg Panels x 2

Parts List



(A) Bolts
M8x10MM x 12



(B) Large Dome Nut
M8x14MM x 12



(C) Small Dome Nut
M6x10MM x 8



(D) Wrench 10MM x 1






(E) Wrench 14MM x 1




(F) Foot Pad x 4

Step 1--


1. Ensure all parts have been removed from the carton and place on a protected surface or carpet.
 2. Check all parts and hardware are the same as the “Parts List”.
 3. Attach Top Shelf (1) to Leg Panels (3) top position. Secure using Bolt (A) with Dome Nut (B) by using Wrench (E).
 4. Repeat above step to assemble Shelves (2) x 2 to Leg Panel (3).
- Note: Please do not fully tighten all Bolts until the console is fully assembled.



- Step 2--**
1. Connect Shelf (1) & (2) and Leg Panel (3) with Small Dome Nut (C) by using Small Wrench (D).
 2. Secure Foot Pad (F) on the bottom of Leg panel as below image.



Step 3-- Place the TV unit onto a flat level surface and level the frame. Once the Table is level, tighten Nut (B) & (C) by Wrench (D) & (E).



Periodically (every 90 days) make sure that the screws are still fully tightened.
ATTENTION: Be certain that all screws are fully tightened before using table.

Step 4-- WE STRONGLY RECOMMEND THIS UNIT IS ATTACHED TO THE WALL TO PREVENT TOPPLE. KEEP YOUR PRODUCT SAFE FROM INJURY.

Wall straps are already pre-assembled on your Furniture.


Assembly Steps to attach your furniture to a wall


1. Use a pencil to mark the fixing positions on the wall.
2. Drill holes and insert appropriate wall plugs into wall (not provided).
3. Place the product against the wall, ensure the strap under top panel.
4. Secure wall strap to the wall with appropriate screws for your wall type (not provided).
Tighten with screwdriver.

Warning:

1. Please note this item needs to be fixed on the wall to prevent falling forward when product is in use.
2. Always ensure intended wall area to be drilled is free from hidden electrical wires, water and gas pipes.

NB: Wall fixings are not included-Please source suitable fixing for your wall type. If in doubt please consult a qualified trades person.





Product Dimension

Limited Warranty

The product you have purchased is warranted against defects in material and workmanship while owned by the "Original Purchaser". The term "Original Purchaser" is defined as that party or entity which purchases these products from an authorized dealer or retailer as shown by the original sales receipt. This warranty does not apply too "as is" or previously owned products.

The manufacturer warrants its products to be free from defects in materials and workmanship (normal wear and tear, fading and stretching excepted), for one year from the date of purchase, except as provided below under the limited warranty.

This warranty gives you specific rights, and you may also have other rights, which vary from state to state (or country to country). All warranties are limited to the Original Purchaser for normal use.

The exceptions or exclusions to this warranty are:

- Upholstery material and foam cushion material is warranted against defects in material and workmanship for a period of one year, beginning on the date of purchase as shown on the original sales receipt.
- Any warranty claim that is submitted after the limited warranty period, or without proper proof of purchase will not include the cost of parts, labor, or delivery on the warranted parts within a reasonable amount of time. We reserve the right to require damaged parts to be returned to us upon request. Natural markings such as scars, brands, grain variations, wrinkles, color variations, etc. will be considered normal characteristics and not construed as defects.
- For claims or questions concerning this warranty, please contact the Customer Service Department on the web at www.trueinnovations.com. Be prepared to provide your name, address, daytime phone number, the model and purchase order number of the product, date of purchase, and the store where it was purchased. The manufacturer requires that the original sales receipt be submitted with all requests to confirm that you are the Original Purchaser according to our written warranty.