




HAIR STYLING STATION

USER MANUAL



Thanks for purchasing OmySalon hair styling station. Please feel free to contact us if you have any problems with assembly or other after-sale issues. OmySalon customer service team is here to assist you. Email: support@omysalon.com; Website: www.omysalon.com. Please attach your user name or order ID so that we can serve you better.







⚠ WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.
- Do not defeat or remove the drawer interlock system.

*This is a permanent label.
Do not remove!*

		 Ø8*40	 M7*50	 M3.5*14
A*39	B*39	C*20	D*2	E*50
 M4*35	 M4*18	 M3.5*16	 M3*14	
F*9	G*4	H*2	I*3	J*6
	 L1 M4*14 L2 M4*35	 Ø20	 N1 N2	
K*10	L*1	M*8	N*2	O*4
 Ø60	 Ø70			
P*3	Q*2			





1



A*20	C*6	E*8	N1*2
	 Ø8*40	 M3.5*14	


2



B*3




3




A*4	C*14	I*2
	 Ø8*40	 M3*14

4



D*2
 M7*50


5



B*4




6



B*17





7



J*6




8




A*6	I*1	L1*1

9




10



B*6




11



E*10	K*10
	
M3,5*14	


12



L2*1

M4*35



13



18×2pcs


E*8	O*4
	
M3.5*14	

14



E*16	G*2
	
M3.5*14	M4*18


15



A*9



16




H*2




M3.5*16

17




B*9	F*9	G*2
	 M4*35	 M4*18

18



E*8	N2*2
 M3.5*14	

19



M*8	P*3	Q*2
 Ø20	 Ø60	 Ø70

20

