




Part List				
Label	Picture	Description	Qty	
A		Table Top	1	
В		Leg	2	
С		Coss Bar	1	
<u>Hardware</u>				
No.	Picture	Description	Qty	
1		Bolt (M6x35mm)	5	
2		Screw (M6x50mm)	3	
3		Allen Key M4	2	



This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.





Your Table is ready for use.

This Table can only be used on a flat, level surface.

Care & Maintenance				
0 555	•	Do not put hot items directly on furniture surface		
0	•	Do not clean furniture with harsh cleansers or polish.		
~ Ö	•	To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.		
✓	٠	Children should not climb or jump on the furniture.		
	•	Do not write on furniture without a padded barrier to protect the surface.		
~ ***	•	To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.		
	٠	Not for commercial use. For residential use only .		
	•	Stains may be removed with mild soap solution and damp cloth.		
	•	Dust and pick-up spills using a clean, non-colored, lint-free cloth .		