


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT


Tools Required For Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1 unit
Headboard Panel




#2 x 2 units
Headboard Leg (L&R)




#3 x 1 unit
Footboard Panel



#4 x 2 units
Side Rail




#5 x 4 units
Bed Slat




#6 x 8 units
Slat Support Leg
225mm x 30mm x 30mm


Hardware List




#A x 6 units
Bolt M6 x 30mm




#B x 6 units
Lock Washer




#C x 6 units
Flat Washer



#D x 8 units
CSK M4 x 32mm



#E x 1 unit
Allen Wrench M4



#F x 1 unit
Allen Wrench M5




#A x 6 pcs
#B x 6 pcs
#C x 6 pcs

"R" Marking behind
the Headboard & Leg

1. With the help of another person,
align the top of the legs (#2L/R) to the
bottom corners of the headboard (#1).


3. Insert the prepared bolt assemblies
into the legs and secure using the
Allen wrench (#E).




2. Prepare 6 bolt assemblies by first
inserting a lock washer (#B) onto the
bolt (#A) then a flat washer (#C) onto
that same bolt (#A).




Untighten the screw half way, then hook the side rails (#4) onto the screw.
Secure with the screw.






1. Insert the threaded ends of the slat support legs (#6) to the holes along the bed slats (#5). Turn right to tighten.




2. Adjust the levelers according to the floor level.



#D x 8 pcs



2. Insert a screw #D into each end and secure using a Phillips screwdriver.



1. Align the ends of the bed slats (#5) to the side rails (#4).

