

The Just Float™ recreational float is designed to be recreational. It is not a lifesaving device. Users should heed the following warnings to enjoy using the Just Float™ recreational float safely. **FAILING TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY OR DEATH.**

- Just Float™ recreational floats are made from polyethylene foam and do not require any other accessories to float.
- Upon unpackaging, ensure there are no sharp objects located near the Just Float™ recreational float that could scratch, mark or tear the float.
- The Just Float™ recreational float includes two straps and a bungee cord, along with a built-in stainless steel grommet.
- Before using your float, inspect the surface for consistency, inclusion of the built-in grommet, bungee cord for anchoring and two float straps which secure the float when rolled.
- The Just Float™ recreational floats are easy to maintain and light weight. Keep your Just Float™ recreational float clean by spraying/wiping it down with general purpose cleaner and rinse with water after use. Allow your float to completely dry.
- When storing your Just Float™ recreational float for long periods of time, ensure the float is completely dry prior to storage. Roll up the float and secure it with the float straps. Store the Just Float™ recreational float away from the elements.
- Ensure all users remove any jewelry or personal accessories that could rip, scar or tear the float surface or edges.
- To preserve the surface of Just Float™ recreational floats along with their vibrant colors, avoid direct sunlight exposure for prolonged periods of time when not in use.
- With continued usage, minor scuffs and surface tears may occur that do not affect the safety and fun of the floats
- Ensure all users are made aware of the bungee system location when the Just Float™ recreational float is anchored. The bungee cord and grommet attachment should remain below the playing surface at all times.