


Wall Cabinet

Instruction Manual



Thank you for shopping with us!

If any part is missing, broken upon receipt or you need any help from us.

**For the FASTEST SOLUTION, please FIRSTLY CONTACT US at our
after-sales email.**

Notes:

1. ASSEMBLY PREPARATION AND TIPS FOR ASSEMBLY

- 1). Remove all packaging materials, staples and packing straps from the carton.
- 2). Refer to Parts List and Hardware List, and ensure parts and hardware are correct before assembly.
Contact customer service for missing parts.
- 3). Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent scratch and damage to parts.
- 4). Allow ample room for assembly and assemble the product near where the product will be placed.
- 5). During assembly, do not over-tighten any fittings as this may cause damage.
- 6). Always place the product on a flat, level surface.








2. CARE AND MAINTENANCE

- 1). KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
- 2). Wipe clean with a soft, dry cloth; avoid the use of harsh chemicals or household cleaners as they may damage the exterior finish of the furniture.
- 3). Hardware may loosen over time. Periodically, check that all connections are tight; re-tighten as necessary.








3. TIPS TO PROTECT & CARE FOR YOUR FURNITURE

- 1). Avoid placing your furniture in direct sunlight, as sunlight causes fading.
- 2). Use a protective pad when writing on the furniture surface.
- 3). Use cutting boards and trivets for food preparation in order to avoid damaging the top for the unit.


PART LIST

A 	B 	C 	D 
Top Panel 1 PC	Bottom Panel 1 PC	Center Fixed Shelf Panel-1 1 PC	Side Fixed Shelf Panel 4 PCS
E 	F 	G 	H 
Door 1 PC	Partition Panel 2 PCS	Side Back Panel 2 PCS	Center Back Panel 1 PC
I 			
Center Fixed Shelf Panel-2 2 PCS			



HARDWARE LIST

#1  Ø5*40mm Screw 40 PCS (Extra 2)	#2  Ø6*30mm Wood Dowel 8PCS (Extra 2)	#3  Ø24*21mm Handle 1 PC	#4  M4*20mm Round Head Bolt 1 PC	#5  45*17*12mm Single Door Magnet 1 PC
#6  30*22*1mm Door Small Plate 1 PC	#7  Ø3*12mm Screw 1 PC	#8  M5*15mm Bolt 2 PCS (Extra 1)	#9  Ø3*14mm Screw 2 PCS (Extra 1)	#10  30*30*17mm Angel Iron 2 PCS
#11  Wall Anchor 2 PCS	#12  Ø4*45mm Long Screw 2 PCS	#13  Piton 20 PCS (Extra 4)	 Hammer 1 PC	 Phillips Screwdriver 1 PC
 25*Ø12mm Center Axis 2 PCS				



ASSEMBLY OVERVIEW





Step 1.





Step 2.





Step 3.





Step 4.





Step 5.





Step 6.




Step 7.




Step 8.




Step 9.



#11 x2




#12 x2



x1

Safety strap kit must be installed to prevent tipping, damage and/or injury.



Warning:

Seller is responsible for the product-related issues occurred upon receipt, but will not be responsible for the personal injury, property damage or loss resulting from the incorrect assembly, improper use, inadequate maintenance or neglect of this product.