



QUILT RACK QR1



If you need assistance, please call 1-877-ENCLUME
Enclume Design Products
 24 Colwell Street, Port Hadlock, WA 98339

Enclosed you will find everything needed for the assembly and use of your quilt rack. Two people make assembly and installation easier.


The parts and hardware included are:

Hardware included:

10 – 3/8" x 1/2" Button Head Screws
 1 – 7/32" Allen Wrench

Components included:

2 – Upright Supports
 2 – Side Cross Supports
 2 – Lower Brackets
 1 – Top Cross Bar (with curled ends)



ASSEMBLY AND INSTALLATION INSTRUCTIONS

Rack Assembly

- 1) Place the side cross bars on the inside of the upright supports and attach with four 1/2" buttonhead screws, going from outside the upright supports through the side cross bars, so that the heads of the screws show from the outside of the rack. Leave loose.
- 2) Place the top cross bar underneath the top of the upright supports. Attach the top cross bar by screwing in the remaining two buttonhead screws from the top of the upright supports through the bottom of the top cross bar.
- 3) Square up your quilt rack and tighten all buttonhead screws with the hex key provided.
- 4) Your quilt rack is now fully assembled and ready to display your favorite quilt or blanket.

WARNING: It is important that your quilt rack is assembled correctly. If the unit is assembled or used incorrectly, it could become unstable and collapse, possibly causing injury.

LIMITED WARRANTY: This product is warranted to be free of material defects, other than that from normal use, for a period of five years from the date of purchase. Customer's exclusive remedy shall be the repair or replacement of the defective product and shall be subject to the following conditions: (1) notice of any defect is received by Enclume within the warranty period and (2) customer returns the defective product to Enclume Design Products, 24 Colwell St., Port Hadlock, WA 98339, postage prepaid within 20 days following a return authorization number (which may be obtained by telephoning the number at the top of this instructions) being provided to the customer by Enclume. There are no other warranties, expressed or implied. THERE ARE NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ENCLUME SPECIFICALLY DISCLAIMS ANY AND ALL INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE PURCHASE OR USE OF ENCLUME'S PRODUCTS.