



Parts list (Subject to actual size; each type of screws and washers has one spare)

General accessories						
	Wheel x5	Hydraulic Cylinder x1	Mechanism x1	Seat x1	Backrest x1	Armrest x2
Optional accessories						
	Electroplated Steel Base x1		Aluminum Alloy Base x1		Plastic Base x1	
					Note: Before installing the chair, please sort the screws and measure the length of the screws for installation	
	Steel Base Cover x1	Headrest x1	Decorative Cover x1	Headrest Screw (M6*30) x2		



Assembled instructions (Subject to Actual Size)

1 Press the wheels into the chair base.	2 Put the hydraulic cylinder into the hole of the chair base.	3 Put on the cover. (Only for the electroplated steel base)	4 Secure the armrests and seat with armrest screws (M6*30) and armrest washers (M6*14). Pay attention to the direction of installation.
5 Secure the mechanism and seat with mechanism screw (M6*20) and washers (M6*16). Pay attention to the direction of installation.	6 Place the backrest to the seat as picture shown. Secure with backrest screws (M8*35) and lock washers (M8) and washers (M8).	7 Set the upper part of assembled chair on the hydraulic cylinder.	8 Secure the headrest and backrest with headrest screws (M6*30), and then put on the cover.
0 1 2 3 4 5 6 7 8 9 10 cm			

Note: Before installing the chair, please sort the screws and measure the length of the screws for installation