



Assembly Instructions

Caution: You must read this before you proceed

Club Chair



Part List

Label	Picture	Description	QTY
A		Chair	1
B		Leg	4





Hardware

Label	Picture	Description	QTY
①		Bolt (M8*25mm)	9

②		Washer	9
③		Spring Washer	9
④		Allen Key	1
⑤		Washer	8

Assembly Preparation

Before
Beginning
Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-




- Save all packaging until finished-

Assembly Steps



This Club Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Club Chair, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.


Step 1



Place the Chair(A) on its back on a clean, non-marring surface as shown above.

Carefully remove the Dust Cover and take out the four Legs(B) and Hardware.

Step 2




Align the mounting positions on the bottom of Chair(A) and Legs(B) as shown above.

Attach Legs(B) to Chair(A) using Bolts(①), Spring Washers(③) and Washers(②) with Allen Key(④).


Tighten all Bolts fully in a sequential manner.

Step 3



If Legs(B) are uneven, please place one or more Washers(5) on either uneven Legs(B) as shown above. Repeat the same process until all Legs(B) are level.


Step 4



Inspect and make sure all parts are connected and fully secured into position. Your Club Chair is ready for use.

This Club Chair can only be used on a flat, level surface.

Care & Maintenance



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Not for commercial use. For residential use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.