
ASSEMBLY INSTRUCTIONS



ATTENTION

Prior to assembly,please check and count all parts and hardware regarding to the list on page 3-4 of the instruction.If there is any part missing or damaged, please send us messages with the part name and number or send us pictures,we will send you the replacement asap.

If you have any questions about the product or assembly,please kindly contact us at anytime, we will solve your problem asap.

Be sure to provide your order ID so we can assist you better .

IMPORTANT INFORMATION

READ CAREFULLY.



KEEP THIS INFORMATION FOR FURTHER REFERENCE.

GENERAL GUIDELINES

If you have any questions about the product or assembly,please kindly contact us at any time, we will solve your problem asap.

NOTES BEFORE YOU START

1. lf an odor is present when first opening the package, please leave the unwrapped product in a shaded and ventilated area for a few days to air out.
2. Open and assemble the item in the area you plan to keep it to avoid excessive heavy lifting.
3. Assemble the product in a spacious space,and on a soft、clean surface to avoid damage and scratches.
4. TWO PEOPLE are recommended for ease in the assembly of this product.
5. Ensure all parts and hardware are avaiable before assembly, lf you find any part is damaged or missing, please email us(cservice7@yeah.net),we will send you the replacement asap.
6. Follow each step in the manual to ensure the proper assembly.
7. You will use the following tools:a Phillips head screwdriver and rubber hammer. The wood dowels may need to be gently tapped in lightly with a rubber hammer.


 (not included)  (not included)

8. We don't recommend using the electric screwdriver.if you use the power screwdriver to tighten the screws,please be slow down,and stop if the screw is already tightened,excessive screwing may damage the screw and product surface.
















WARNINGS

1. Please be careful and slowly when opening and assembling the product,especially keep the parts and packaging away from children to avoid accidental injury.
2. Please avoid using aggressive chemicals/cleaners to avoid damaging the product surface.
3. Don't push or pull the product to avoid damaging your floor.
4. Don't throw away any packing materials and accessories until assembly is complete.

Exploded Drawing




HARDWARE LIST

A  M5x60mm 6PCS spare:1	B  M6x70mm 4PCS spare:1	C  M6x35mm 8PCS spare:1	D  Ø8x30mm 12PCS spare:2
E  M6x70mm 4PCS spare:1	F  4PCS spare:1	G  M6mm 4PCS spare:1	H  40x40mm 4PCS spare:2
I  Ø10mm 4PCS spare:1	J  M4x14mm 2PCS	K  Ø6x30mm 2PCS	L  Ø20mm 8PCS spare:2
M  M4x40mm 2PCS	N  M10mm 1PC	O  M4mm 1PC	P  M4mm 1PC
Q  2PCS			

STEP 1


M6x60mm		M4mm	
A	X 4	P	X 1



STEP 2


The E should be
fully tighten.

M6x70mm	
E	X 4



STEP 3

Ø8x30mm			M6mm		M10mm	
D	X 4	F	X 4	G	X 4	N	X 1





This step requires two people to work together to assemble.

STEP 4

M6x35mm		Ø20mm		M4mm	
C	X 8	L	X 8	P	X 1

NOTE:Please don"t full tighten any bolts yet,when every parts is OK then you fully tighten all bolts.







STEP 5


M6x60mm		M6x70mm		Ø8x30mm		M4mm	
A	X 2	B	X 4	D	X 8	O	X 1

This step requires two people to work together to assemble.




STEP 6






STEP 7

Ø10mm		M4x14mm			
I	X 2	J	X 2	Q	X 2



STEP 8







Ø6x30mm	
K	X 2

1.Place the console table in the desired position,then mark the center of pre-drilled holes on wall with pencil.

Wall




2.Drill holes following the marks.




3.Tap the wall anchor(K) into the drilled holes with a hammer.

STEP 9

	Ø10mm		M4x40mm
I	X 2	M	X 2




⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:
- •ALWAYS install tipover restraint provided.
- •NEVER put a TV on this product.
- •NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- •NEVER open more than one drawer at a time.
- •Place heaviest items in the lowest drawers.
- •Do not defeat or remove the drawer interlock system.

This is a permanent label.
Do not remove!


⚠ ATTENTION



Des enfants sont morts du basculement des meubles. Pour réduire le risque de basculement des meubles:
- • TOUJOURS installer la retenue de basculement fournie.
- • NE JAMAIS mettre de téléviseur sur ce produit.
- • NE JAMAIS permettre aux enfants de se tenir debout, de grimper ou de s'accrocher à des tiroirs, des portes ou des étagères.
- • N'ouvrez JAMAIS plus d'un tiroir à la fois.
- • Placez les objets les plus lourds dans les tiroirs les plus bas.
- • Ne désactivez pas et ne retirez pas le système de verrouillage du tiroir.

Ceci est une étiquette permanente.
Ne pas enlever!

⚠ WARNUNG



Kinder sind an einem Möbelkipp gestorben. So verringern Sie das Risiko eines Umkippens von Möbeln:
- • Installieren Sie IMMER die mitgelieferte Kipprückhaltevorrichtung.
- • Stellen Sie NIEMALS einen Fernseher an dieses Produkt.
- • Lassen Sie Kinder NIEMALS an Schubladen, Türen oder Regalen stehen klettern oder hängen.
- • Öffnen Sie NIEMALS mehr als eine Schublade gleichzeitig.
- • Legen Sie schwerste Gegenstände in die untersten Schubladen.
- • Besiegen oder entfernen Sie das Schubladenverriegelungssystem nicht.

Dies ist ein dauerhaftes Etikett.
Nicht entfernen!