


SETUP INSTRUCTIONS

What You Need:

Paper Clip, Scissors, and a Friend!




1 UNPACK




Remove beanbag components from the box - this is easiest with the help of a friend.

2 UNROLL




Take the bag of EcoFoam stuffing, and unroll it from its protective outer plastic wrapping.

3 FLATTEN




Unfold and flatten the EcoFoam stuffing.

4 CUT



Cut and then remove the outer wrapping from the EcoFoam stuffing - this is easiest with scissors.

5 UNZIP




WHERE ARE MY ZIPPER PULLS?

They're not lost! For child safety and durability reasons, we intentionally remove them before shipping. That's why we suggest using a paperclip for this step.


Remove the fabric cover from its packaging and locate the zipper. Use your paperclip as a pull tab by threading one end through the slider body, and unzip. Set aside the paperclip.

6 STUFF




Open the fabric cover completely, and assemble the beanbag by stuffing the EcoFoam stuffing inside.

7 FLUFF



Help break up the EcoFoam stuffing by fluffing the beanbag with your hands.

8 EXPAND



Your beanbag will now need time to expand to its maximum size - this can happen as quickly as 6 hours and can take up to 7 days. Enjoy!