



Instruction Manual

Floor Lamp



Overview



Assembly Instruction

1. Rotate the Rod (C) onto the Lamp base (B) in sequence, and pull out the wires from the bottom.
2. Rotate Socket assembly (E) counter-clockwise by two turns, then screw Socket assembly (E) onto Rod (C) and tighten.
3. Insert Harp (F) into Saddle (D).
4. Install E26 bulb (not included) into socket.
5. Attach Lamp shade (G) onto Harp (F) and tighten it with Finial (H).

Product Specifications

Input voltage	120V
Rated power	60W MAX
Lamp socket	E26
Cord Length	7ft.

Product Packaging

Lamp base assembly × 1
Rod × 3
Lamp shade × 1
Harp&Finial × 1
Lamp manual × 1

Safety Warning:

BULB TYPE:


Use only the bulb type and wattage indicated on Wattage Label placed on or near socket.

WARNING: NEVER EXCEED MAXIMUM WATTAGE
Indicated as bulb may cause fire.

CAUTION:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature. This plug can be used in a polarized outlet only one way. If plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.

DO NOT ALTER THE PLUG!



PROPER LAMP CARE:

Use a soft cloth to dust your lamp on a regular basis. Never use chemicals or an abrasive cleaner, to do so may damage the finish on your lamp.

TROUBLESHOOTING:

If fixture does not work:

1. Turn off electrical power and check all wire connections.
2. Check fuse or circuit breaker and replace if necessary.
3. Check to make sure light bulb is in working order.

CONTACT US

E-mail: service@24h-reply.com