






CARE AND MAINTENANCE


Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
 The use of steam or water-based cleaners may cause excessive shrinking or staining.

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Parts List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat		1X
B	Wooden base		4X
HW1	Allen Key		1X
HW2	Socket Bolt 8 x 1 x 70 mm		4X
HW3	Flat washer 8.5 mm		4X

Product Dimensions: 70.07" W x 35.43" D x 33.07" H



Weight Capacity: 825 lbs
WARNING: DO NOT STAND ON SOFA
WARNING: DO NOT OVER TORQUE BOLTS/SCREWS



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
 If any part is missing or damaged, do not attempt to assemble the product.
 Estimated Assembly Time: 10 minutes.
 Tools Required for Assembly (included): Allen Key

