

# Assembly Instructions

Caution: You must read this before you proceed

## Bar Table



### Parts List


Label	Picture	Description	QTY
A		Table Top	1
B		Left Pannel	1
C		Right Pannel	1
D		Left Back Pannel	1
E		Right Back Pannel	1
F		Middle Pannel	1
G		Bottom Panel	1

### Hardware

Label	Picture	Description	QTY
①		Bolt(M6*35mm)	23
②		Washer	23
③		Allen Key	1

# Assembly Preparation


Before Beginning Assembly:



-  • Read instructions, cover to cover-
-  • Have 2 adults on hand for assembly-
-  • Do not assemble on flooring or carpet-
-  • Assemble on a clean non-marring surface (packing foam)-
-  • Save all packaging until finished-


# Assembly Steps

## Overview



This Bar Table has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Bar Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

## Step 1




Open the carton and place all the parts onto a clean, non-marring surface.  
Attach Left Back Panel (D) to Right Back Panel (E) using Bolts(①) and Washers(②) with Allen Key(③) as the picture show.

**DO not fully tighten the Bolts.**

**ATTENTION: Occasionally some of the PE Wicker shifts and covers the mounting positions preventing easy assembly. The PE wicker should never be cut, but moved away from the mounting positions.**


## Step 2



Attach Right Panel (C) to Right Back Panel (D) and Left Panel (B) Left Back Panel (C) using Bolts(①) and Washers(②) with Allen Key(③) as the picture show.

**DO not fully tighten the Bolts.**

## Step 3



Step3.1


Step3.2

Step3.1 Attach Middle Panel (F) & Left Panel (B) and Right Panel (C) using Bolts(①) and Washers(②) with Allen Key(③) as the picture show.

Step3.2 Attach Bottom Panel (G) & Left Panel (B) and Right Panel (C) using Bolts(①) and Washers(②) with Allen Key(③) as the picture show.

**DO NOT fully tighten the Bolts.**

## Step 4



Attach Table Top (A) & Left Panel (B) and Right Panel (C) using Bolts (1) and Washers (2) with Allen Key (3) as the picture show.  
**DO not fully tighten the Bolts.**

## Step 5



Stand the Table up and check for stability.  
Then proceed to tighten all Bolts at all joints.

**Note: DO NOT fully tighten a BOLT in one go and then move on to the next. Rather, in a sequential manner, gradually tighten each Bolt until all bolts are evenly secured. This methodology will ensure maximum evenness once all Bolts are fully tightened.**

## Step 6



You Bar Table is ready for use .  
**The Bar Table should only be used on a flat, level surface.**

## Care & Maintenance

-   ● Do not put hot items directly on furniture surface
  -   ● Do not clean furniture with harsh cleansers or polish.
  -   ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
  -   ● Children should not climb or jump on the furniture.
  -   ● Do not write on furniture without a padded barrier to protect the surface.
  -   ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
  -   ● Not for commercial use. For residential use only .
  -   ● Stains may be removed with mild soap solution and damp cloth.
  -   ● Keep away from sources of ignition.
- 
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .

### What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

### Why Did I Find a Proposition 65 Warning on My Home Goods Product?


We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

### Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

### Just How Common Are Proposition 65 Warnings?


Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:



# Assembly Instructions

Caution: You must read this before you proceed

## Barstool



### Parts List

Label	Picture	Description	QTY
A		Seat	1
B		Leg	1
C		Leg	1
D		Footrest	2

### Hardware

Label	Picture	Description	QTY
①		Bolt(M6*15mm)	13
②		Washer	13
③		Allen Key	1

# Assembly Preparation


## Before Beginning Assembly:



-  • Read instructions, cover to cover-
-  • Have 2 adults on hand for assembly-
-  • Do not assemble on flooring or carpet-
-  • Assemble on a clean non-marring surface (packing foam)-
-  • Save all packaging until finished-


# Assembly Steps

## Overview



This Barstool has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Barstool parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.


## Step 1



Open the carton and place all the parts onto a clean, non-marring surface.  
Attach Footrests(D) to Leg(C) using Bolts(1) and Washers(2) with Allen Key(3) as shown in the picture.

**Do not fully tighten the Bolts.**


## Step 2



Attach Leg(B) to Footrests(D) using Bolts(1) and Washers(2) with Allen Key(3).

**Do not fully tighten the Bolts.**

## Step 3




Attach Seat(A) to Leg(B) and Leg(C) using Bolts(1) and Washers(2) with Allen Key(3) as the shown above.

**Do not fully tighten the Bolts.**

**ATTENTION: Occasionally some of the PE Wicker shifts and covers the mounting positions preventing easy assembly. The PE wicker should never be cut, but moved away from the mounting positions.**

## Step 4



Place the Barstool on a **LEVEL SURFACE** to check for wobbles.

If it wobbles, lift the Barstool some 30cm to 50 cm high from the ground.

Keep your feet and toes well away from the drop zone.

Drop the Barstool freely and vertically with all four legs, hitting the ground, all at the same time.

This Drop Test will help to ensure that all the Bolts and gaps reach full alignment status.

Test again for evenness on a **LEVEL SURFACE**.

If no wobbles are found, slowly and steadily, place the Barstool facedown.

Then, proceed to tighten all Bolts in a sequential manner.


**When tightening the Bolts, tighten sequentially.**

**DO NOT** tighten any Bolt fully and then move on towards the next one.

**This could cause the frame to warp. If there are still wobbles, loosen the Bolts and execute the same drop test.**

**If the Barstool is not stable, it could lead to damage to the product.**

## Step 5



Your Barstool is ready for use.

**This Barstool can only be used on a flat and level surface.**

## Care & Maintenance

-   ● Do not put hot items directly on furniture surface
  -   ● Do not clean furniture with harsh cleansers or polish.
  -   ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
  -   ● Children should not climb or jump on the furniture.
  -   ● Do not write on furniture without a padded barrier to protect the surface.
  -   ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
  -   ● Not for commercial use. For residential use only .
  -   ● Stains may be removed with mild soap solution and damp cloth.
  -   ● Keep away from sources of ignition.
- 
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .

### What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

### Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

### Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

### Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

