


Canopy

Instruction Manual

HW-ZDZP-10FT




✉ HJ-Customer-Service@outlook.com

☎ (909)637-7665 | (909)637-7593

EST 9:00AM--17:00PM

Package List


A X1




B X1




C X4



D X4



E X4



When using the product, basic safety precautions should always be followed to reduce the risk of injury including the following:

CAUTION Risk of injury! Do not climb on top of the product. Falling off the product can result in serious injury.

CAUTION Risk of injury and property damage! Do not use this product in adverse weather conditions, such as strong winds, heavy rains and snow. Disassemble the product when the wind speed exceeds Beaufort scale 5 (>25 mph / >40 km/h).

- **This product must be assembled by 2 competent adults.**
- For domestic outdoor use only.
- This product is designed for occasional use and cannot be used as a permanent structure.
- Never stay under the product in thunderstorms.
- Keep children and pets away while assembling the product.
- Always use the product on a firm, level ground.
- To avoid bending, anchor the product to the ground using provided pegs or sandbags.
- Do not use this product if any parts are missing, damaged, or worn.
- Regularly examine the product for wear and tear. Stop using the product at first sign of damage or if parts become detached.
- Keep this product away from naked flames and direct sources of heat, such as patio heaters or barbeques. Do not use candles, matches or open flames of any kind in or near the product.
- Do not smoke or store flammable liquids inside the product.
- When using several products together, keep at least 10' (3 meters) distance between each product. Do not to combine/connect several products together.
- Build campfire downwind and at least 10' (3 meters) away from the product. Fully extinguish the campfire before leaving.
- Do not hang from the ribs, frame or canopy of this product.
- Empty water pockets as soon as they form.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Before First Use

- Check the product for transport damages.
- Remove all the packing materials.

⚠ DANGER Risk of suffocation! Keep any packaging materials away from children – these materials are a potential source of danger, e.g. suffocation.

Cleaning and Maintenance

Cleaning


- To clean the product, wipe with a soft, slightly moist cloth.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.
- In case of mold stains, remove them with a mild soap.
- Do not use a high-pressure washer for cleaning of this product.

	Do not wash		Do not bleach.
	Do not tumble dry.		Do not dry clean.
	Do not iron.		


Maintenance

- Regularly check that all the components and fasteners are tightened.
- Store the product in a cool and dry place away from children and pets, ideally in the provided storage bag.


Step 1



Step 2



Step 3




Step 4



Step 5-1



Step 5-2



NOTE: Sandbags need to be filled by themselves.



Technical Support

(909)637-7665 | (909)637-7593

Other Info

HJ-Customer-Service@outlook.com

Thank you for choosing this product. We strive to provide you with the best quality products and services in the industry. Should you have any issues, please don't hesitate to contact us.