


ASSEMBLY INSTRUCTION

DINING CHAIR




N715P487121




IMPORTANT NOTE:

- 1: PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.**
- 2: BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.**
- 3: DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIRS ARE FULLY SET - UP.**

Detail View




Part List

		
BACK FRAME (3 pc)	SEAT FRAME (3 pc)	FRONT LEGS (6 pcs)


Hardware List

 1/4"x70 mm BOLT (12 pcs)	 1/4"x50 mm BOLT (12 pcs)	 1/4"x35 mm BOLT (6 pcs)	 1/4"x11 mm LOCK WASHER (30 pcs)
 1/4"x19 mm FLAT WASHER (30 pcs)	 4x58mm ALLEN KEY (1 pc)		


STEP 1:




STEP 2:



STEP 3:



STEP 4:



FULLY

