

## ASSEMBLY INSTRUCTION

Caution : You must read this before you proceed


### Care & Maintenance

- ⊗  • Not for commercial use. For residential use only.
- ✓  • Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- ⊗  • Do not put hot items directly on furniture surface.
- ⊗  • Do not clean furniture with harsh cleansers or polish.
- ⊗  • Do not place furniture under direct sunlight.
- ⊗  • Do not place furniture near heating or cooling vents.
- ⊗  • Do not write on furniture without a padded barrier to protect the surface.
- ⊗  • Do not place furniture outside. For indoor use only.
- ⊗  • Stains may be removed with mild soap solution and damp cloth.
- ⊗  • Children should not climb or jump on the furniture.





- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware packs and legs.  
Sets often ship in multiple boxes and may arrive a day or two apart.


**DINING CHAIR**  
**N768P466350**



**Parts List**


| Label | Picture                                                                             | Description     | QTY |
|-------|-------------------------------------------------------------------------------------|-----------------|-----|
| A     |  | Right frame leg | 1   |
| B     |  | Left frame leg  | 1   |
| C     |  | Seat cushion    | 1   |
| D     |  | Backrest frame  | 1   |

## HARDWARE LIST

| Label | Picture                                                                             | Description           | QTY  |
|-------|-------------------------------------------------------------------------------------|-----------------------|------|
| ①     |    | Bolt (1/4" x80mm)     | 8+1  |
| ②     |    | Bolt (1/4" x45mm)     | 2+1  |
| ③     |    | Spring washer (10mm)  | 10+1 |
| ④     |    | Flat washer (19mm)    | 8+1  |
| ⑤     |    | Allen wrench (M4)     | 1+1  |
| ⑥     |   | Dowel (Ø10x40mm)      | 6+1  |
| ⑦     |  | Cover sticker (Ø21mm) | 2+1  |
| ⑧     |  | Felt pad              | 2    |

## Assembly Preparation

Before begining  
Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand fo assembly-



- Do not assemble on flooring of carpet-




- Assemble on a clean non-marring suface (packing foam)-



- Save all packaging until finshed-

## Assembly Steps


### Overview



This chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the chair parts, the above picture is provided to help you put the various parts into perspective. Please read through the instructions below to familiarize yourself with the parts and steps before assembly.


**CAUTION :** When tightening these screws, tighten sequentially. DO NOT tighten any screw fully and then towards the next one. This would cause the frame to warp. If there is still wobbles, loosen the screws and execute this same process. **WARNING!! IF IT IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.**

## Step 1




Attach the dowel ⑥ to the beackrest frame D, seat cushion C.

## Step 2




Attach the seat cushion C into the right frame leg A. Using bolt ①, spring washer ③, flat washer ④ and allen wrench ⑤. Do not fully tighten the bolts.

### Step 3




Attach the left frame leg B, the backrest frame D to the right frame leg A and seat cushion C. Using bolt ①, dowel ⑥, spring washer ③, flat washer ④ and allen wrench ⑤. Do not fully tighten the bolts.

## Step 4




Attach the backrest frame D to the right frame leg A and the left frame leg B. Using bolt ②, spring washer③ and allen wrench⑤. Do not fully tighten the bolts.

After checking the chair, if no problem, tighten all the bolts.  
Stand the chair up.  
Place the chair on a LEVEL SURFACE to check for wobbles.




After inspection, attach the cover stickers ⑦ hidden the bolt holes .

## Step 5



Note: If missing or fall out the felt pad, attach new one ⑧.



Your chair is ready for use.  
This chair can only be used on a flat, level surface.