

Installation Manual

Mounting Bracket
1 PCS

Bell Cover
1 PCS

Light Source
1 PCS

Controller
1 PCS

Remote Control
1 PCS

Canopy
1 PCS


Motor
1 PCS

Lampshade
1 PCS

Lamp Plate
1 PCS

Fan Blade
4 PCS


Downrod
1 PCS



Accessories Pack
1 PCS


Note: Please check the product components according to this list.
If any item is missing, please contact customer service.

Remove the 12 screws from the motor and the 3 screws from the lamp plate.




01

Install the fan blades and tighten the screws.




02

Lamp Plate Installation




03

Connect the light source wire, install the light source, and screw the lampshade clockwise.




04



1. For wooden ceilings, use wood screws to install the suspension bracket.
2. For concrete ceilings, use expansion bolts to install the suspension bracket.


05



Insert the downrod, install the safety pin and R-pin, and tighten the screws with a Phillips screwdriver.


06

Connect the Wires




07

Mount the lamp body onto the hanging bracket.




08



Safety Notice: Turn off the power before installation. Installation must be performed by a professional technician.


09

Remote Control Instructions



Pairing Procedure:

After turning on the power, press and hold the “” button within 5 seconds after the light turns on. Once you hear a beep or see the light flash, the pairing is successful. If pairing needs to be performed again, wait 30 seconds before turning on the power and repeating the above steps.



Care and Maintenance

1. Regular Cleaning:

It is recommended to clean the fan blades and lampshade every 1-3 months using a soft dry cloth or slightly damp cloth, avoiding dust buildup that may affect airflow and heat dissipation. Do not allow water to enter the motor.

2. Power Off Before Maintenance:

Always disconnect the power before cleaning, inspection, or maintenance to prevent electric shock or accidental operation.

3. Keep a Dry Environment:

This product is not waterproof. Do not use it in humid areas such as bathrooms or kitchens, and avoid exposure to rain or moisture.

4. Check Fasteners:

Regularly inspect the bracket, screws, and installation parts for looseness and tighten if necessary to ensure safe operation.

5. Maintain Proper Ventilation:

Do not hang objects around the light or fan to avoid blocking air inlets or outlets and ensure proper ventilation performance.

6. Avoid Strong Impacts:

Avoid severe vibration or impact which may cause structural deformation, motor damage, or loosening of components.

7. Inspect Wiring and Connections:

Regularly check whether the power cord is worn, loose, or damp. If any issue is found, stop using immediately and contact a professional.

8. Long-Term Storage:

If not used for a long time, disconnect the power and periodically run the device for a few minutes to maintain motor performance.

9. Avoid Extreme Weather:

Do not use or expose the product outdoors during severe weather such as typhoons or heavy rain.

10. Do Not Disassemble:

Do not disassemble or repair the product by yourself. Contact professional technicians or dealers for maintenance.



1. Disconnect the power before installation. Do not cover the lamp or block heat dissipation. Do not use the product in humid areas (such as bathrooms). Keep this product out of reach of children. Do not disassemble or repair the product without authorization.

2. This product is electrical and electronic equipment and must not be disposed of as household waste. According to local regulations, please deliver it to an authorized collection point for used equipment. Proper disposal helps protect the environment and avoid health risks.