


ASSEMBLY INSTRUCTION



+ Do Not Use Power Tools



+ Suggested Adults



NOTE: For questions about parts or assembly please call us

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 **IMPORTANT SAFETY INFORMATION**

Do not assemble the product if any of the following parts arrived damaged:

- Part # - Left Chaise Base
- Part # - Armless Loveseat Base
- Part # - Right Chaise Base
- Part # - Pillow
- Part # - Back Cushion
- Part # - Gold Leg
- Part # - Chrome Leg

Do not assemble if any of the following Hardware parts missing:


- Part # - Allen Wrench
- Part # - Bolt
- Part # - Washer

2 **IMPORTANT ASSEMBLY INFORMATION**


Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Parts Included


① LEFT CHAISE BASE 1PC




② ARMLESS LOVESEAT BASE 1PC



③ RIGHT CHAISE BASE 1PC




④ PILLOW 4PCS




⑤ BACK CUSHION 4PCS



⑥ GOLD LEG 13PCS



⑦ CHROME LEG 13PCS



+ Hardware Included

A ALLEN WRENCH
M6*57mm 1PC



B BOLT
M6*35mm 52PCS




C WASHER
M6*16mm 52PCS



ASSEMBLY INSTRUCTION

1



2

