

**Product Guide &  
Assembly Instructions**

➤ **CLICK365™**



**Alcott**  
**Side Table**

# Important

## Retain for future reference

Should you prefer to speak with a customer service representative, you may call toll free:

---

1-855-372-2315

---

U.S. 6am - 5pm PST

---

0-800-051-6775

---

U.K. 2pm - 1am

# Before You Start

## Things You Need To Know

Number of people required to assemble



Time to assemble - **20 Min**

Tools NOT supplied for assemble



## Guidelines

**FAILURE TO FOLLOW THESE WARNINGS  
WHEN IN USE COULD RESULT IN INJURY**

### DO

We suggest you spend a short time reading through the leaflet before you start

When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.

Unwrap **all** packing materials and place the components on a clean surface to protect them from damage. We recommend using the product packaging to protect your floor during assembly.

Carefully check that you have **all** the parts before beginning assembly.

Due to the size of this product, we recommend assembly in the room intended for use.

Make sure the product is **fully** assembled as **illustrated** and that **all** connections are **fully** tightened before use.

Wipe occasionally with a soft, damp cloth then buff dry with a soft clean dry cloth.

The wood **will** mellow and change color over time. As a result, we recommend that ornaments and items placed on the surface are moved regularly for the first few months to prevent an uneven mellowing.

Check **all** bolts and screws every 90 days. As necessary tighten if any are loose.

Keep **small** parts and pieces away from children and pets until **fully** assembled.

# Before You Start

## WARNING:

**DO NOT LET CHILDREN PLAY IN  
OR AROUND THE UNIT DUE TO THE  
POSSIBLE RISK OF INJURY.**

---

## Guidelines

FAILURE TO FOLLOW THESE WARNINGS  
WHEN IN USE COULD RESULT IN INJURY

## DON'T

Do not drag or pull your furniture.

Do not rub or scrub the surface when cleaning.

Do not use silicone based furniture polish. Silicone in furniture polishes can break down the finish.


Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or finishes to de-laminate.

Do not place hot items (e.g. hot drinks) directly on to the wood surface. Please make sure you use a placement or coaster.


Do not stand on the item or use as a step ladder.



## Product Dimensions




# Getting To know Your Product




# Parts List


Components supplied. Please use this guide if you require replacement parts.  
Fixtures and fittings supplied (not to scale)




(1) Top Panel x1




(2) Front Panel with Door x1




(3) Back Panel x1




(4) Drawer Track x1




(5) Lower Cross Bar x2




(6) Shelf x1




(7) Side Panel x2




(8) Drawer Front Panel x1



(9) Drawer Back Panel x1



(10) Drawer Side Panel x2



(11) Drawer Bottom Panel x1

# Parts List



(A) Knob x2  
25\*23mm



(B) Bolt x2  
M4x20mm





(C) Screw x16  
M4x30mm  
(Spare x2)



(D) Wood Plug x8  
10x8mm  
(Spare x2)



# Step 1

1. Make sure all parts have been removed from the carton and placed on a protected surface or carpet.
2. Check all parts and hardware against the "Parts List" and "Hardware List".
3. Connect the top panel (1) to back the panel (3) by using screws (C) as shown below. Make sure the grooves are aligned before tightening the screw.




## Step 2


1. Insert the side panel (7) as shown below.
2. Connect the lower cross bar (5) by using screws (C) as shown below.
3. Insert the drawer track (4) as shown below.



## Step 3


1. Connect the front panel (2) to the unit by using screws (C) as shown below.



C		
M4x30	4	



## Step 4

1. Attach the knob (A) to the door by using a bolt (B) as shown below.
2. Insert the shelf (6) to the cabinet as shown below.




A	B
	
Φ25x23	1
M4x20	1




## Step 5

1. Connect the drawer front (8) to the drawer side (10) by using screws (C) as shown below. Make sure the grooves are aligned before tightening the screw.
2. Connect the drawer bottom (11) and drawer back (9) to the unit by using screws (C) as shown below.
3. Attach the knob (A) to the unit of by using a bolt (B) as shown below.




## Step 6

1. Insert the drawer to the unit by rotating the wood stopper to hold the drawer as shown below.




## Step 7

1. Insert the wood plug (D) to cover the screw hole as shown below.



# Product



Periodically (every 90 days) make sure the screws are still fully tightened.

**ATTENTION:** Be certain that all screws are fully tightened before using the side table.

# Limited Warranty

The manufacturers products are warrantied against defects in material and workmanship while owned by the “Original Purchaser”.

The term “Original Purchaser is defined as the party or entity which purchases this manufacture’s furniture from an authorized retailer as shown by the original sales receipt. This warranty does not apply to “as is” or previously owned products.

The manufacturer warrants its products to be free from defects in materials and workmanship (normal wear and tear, fading and stretching excepted), for one year from the date of purchase, except a provided below under the limited warranty.

## **The exceptions or exclusions to this warranty are as follows:**

Any warranty claim that is submitted after the limited warranty period, or without proper proof of purchase will not include the cost of parts, labor, or delivery.

This warranty shall not apply to the manufacturer’s products which have been subjected to misuse, neglect, alteration, modifications, or attachments, either caused by the Original Purchaser, shipping, storage, accident, fire, flood, or acts of God.

In the event of a defect in material or workmanship covered by this warranty, the manufacturer will repair or replace, at their discretion, without charge the warrantied parts be returned to us upon request. Natural markings such as scars, brands, grain variations, wrinkles, color variations, etc. will be considered normal characteristics and not construed as defects.

For claims or questions concerning this warranty, please reach us by email at **service@clickdecor.com**. Be prepared to provide your name, address, daytime phone number, the model and purchase order number of the product, date of purchase, and the website where it was purchased. The manufacturer requires that the original sales receipt be submitted with all requests to confirm that you are the Original Purchaser according to our written warranty.

This warranty gives you specific rights, and you may also have other rights, which vary from state to state. All warranties are limited to the Original Purchaser for normal use.

▶ **CLICK365™**



Click365\_Alcott Side Table-0823