
# 

#### ASSEMBLY INSTRUCTIONS


#### SKU:V-CB24-0642



#### PARTS IDENTIFICATION





#### PARTS IDENTIFICATION





3

#### HARDWARE IDENTIFICATION



































A. x2PCS Q. x1PC Ć















B. x2PCS


Q. x1PC

























14

























#### FURNITURE CARE AND MAINTENANCE

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



#### MAINTENANCE

Tighten all bolts and screws again within the first 2 weeks of assembly Check the tightness of all bolts every 2 months, tighten them if necessary



#### CLEANING

Clean the surface of the MDF and PB (medium - density fiberboard) with a lightly dampened cloth.

- Small amount of mild soap can be used if necessary
- Dry the surface immediately after cleaning.

DO NOT use bleach or alcohol detergent to clean the surface.
DO NOT apply wood treatment on parts made with MDF/PB.

Medium - density fiberboard and PB will swell and distort when suffer from water damage. Make sure to dry the furniture immediately after cleaning