



Hardware			
Label	Picture	Description	QTY
1		Allen Key	1
2		Bolt (M6*30mm)	7
3		Bolt (M6*40mm)	8
4		Bolt (M6*95mm)	3
5	$\bigcirc$	Washer	16
6	$\bigcirc$	PE Cap	3
Assembly Preparation			
Before Beginning Assembly:			
<ul> <li>Read instructions, cover to cover-</li> <li>Have 2 adults on hand for assembly-</li> <li>Do not assemble on flooring or carpet-</li> <li>Assemble on a clean non-marring surface (packing foam)-</li> <li>Save all packaging until finished-</li> </ul>			am)-



This Loveseat has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Loveseat parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

NOTE: It is recommended that you have a partner to assist durning the entire assembly process.



Open the carton and place all the parts onto a clean, non-marring surface.


Hold the Chair Seat (C) up and align the mounting positions to the Left Armrest(B).

**Step(1-1)** Attach Chair Seat(C) to Left Armrest(B) using Bolt(2) and Washer(5) with Allen Key(1).

**Step(1-2)** Attach Chair Seat(C) to Left Armrest(B) using Bolt(③) and Washer(⑤) with Allen Key(①).

Only loosely tighten the Bolts.


ATTENTION: There may be some PE wicker that may have covered the Bolt points. To ease assembly, guide and slide the PE wicker away from the mounting positions. DO NOT CUT AWAY any PE WICKER as this would cause the wicker to unravel!



**Step2-3)** Attach Chair Back(D) to the Left Armrest(B) and Chair Seat(C) using Bolt(2) and Washer(5) with Allen Key(1).

**Step2-4)** Attach Chair Back(D) to the Left Armrest(B) and Chair Seat(C) using Bolt(③) and Washer(⑤) with Allen Key(①).


Only loosely tighten the Bolts.



**Step4-6,7)** Attach Right Armrest(A) to the Right Armrest(B) and Chair Back(D) using Bolt(③) and Washer(⑤) with Allen Key(①).

**Step4-8,9,10)** Attach Right Armrest(A) to the Right Armrest(B) and Chair Back(D) using Bolt(2) and Washer(5) with Allen Key(1).

## Only loosely tighten the Bolts.



Turn the Loveseat right side up.

Place the Loveseat on a LEVEL SURFACE.

Inspect it and make sure all parts are adequately connected.

Gently sit on the Loveseat.

This will help to align all parts at all joints.

Then carefully get off the Loveseat, and in a sequential manner, proceed to tighten all Bolts.

When tightening the Bolts, tighten sequentially.


DO NOT tighten any Bolt fully and then move on to the next one.

This may cause the frame to warp.

If there is still wobbles, loosen the bolts and execute this same process. If the Loveseat is not stable it could lead to damage to the product.

Place PE Caps(6) on Bolts as shown.

<u>Step 7</u>



Put the Seat Cushion(F) and Back Cushion(E) on the Loveseat. Your Loveseat is ready for use.

Care &	Maintenance
0 5.	Do not put hot items directly on furniture surface
0 Å ·	Do not clean furniture with harsh cleansers or polish.
⊘ Ö∶•	To obtain the longest lifespan of your outdoor prodets, minimizing exposure to direct sunlight is recommended.
◎ 🏋	<ul> <li>Children should not climb or jump on the furniture.</li> </ul>
01	<ul> <li>Do not write on furniture without a padded barrier to protect the surface.</li> </ul>
° ↔	To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
	<ul> <li>N ot for commercial use. For residential use only.</li> </ul>
0	<ul> <li>Stains may be removed with mild so ap solution and damp cloth.</li> </ul>
•	<ul> <li>Keep away from sources of ignition.</li> </ul>
10	Dust and pick-up spills using a clean, non-colored, lint free cloth.

## What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning. Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

