


Assembly Manual



ASSEMBLY INSTRUCTION






friendly reminder

To avoid errors and confusion during the installation of accessories, use the type and quantity of hardware accessories according to the installation procedure described in the instructions. First, unroll the accessories bag and lay out the hardware accessories, cut holes in the side, and take out the hardware accessories

Packaging Details




A	X26+2	B	X26+2	C	X24+2	D	X4+1	E	X8+1	F	X1
Ø6×35		Ø15×10		Ø6×30		Ø5×38					

G	X2	H	X14+2	I	X1	J	X26+3	K	X14+2		X1
		Ø3×12		Ø4×12 Ø4×38		Ø3.5×12		Ø20mm			


Step 1

A	X2




Step 2

A	X2





Step 3

B	X4
	
C	X4
	





Step 4

A	X4
	
H	X4
	
F	X1
	




Step 5




C	X4
	
D	X4
	


Step 6

A	X8
	






Step 7




I	X1
B	X4
C	X4




Step 8

B	X4
C	X4



Step 9


A	X2



Step 10


Keep both ends
flush before locking
component B

B	X2




Step 11

A	X4




Step 12

A	X4




Step 13

B	X8
	
C	X4
	




Step 14


B	X4
	
C	X4
	




Step 15




J	X10



Step 16




J	X12




Step 17


J	X4





Step 18


E	X8



















Step 19

H	X2
	
F	X1
	
G	X2
	




H	X4
	




Step 20


H	X4
	




Step 21

I	X1
	


The cabinet must be permanently fixed to the wall
Equipped with an anti-tipping device to prevent cabinet don't tip over
Mark the position of the drill on the wall with a pencil.
Drill holes at the marked locations with a drill bit.
Insert the wall anchor (I) gently into the hole
Knock in this wall anchor (I).
Lock the strips to the wall
Equipped with screws (I).





Step 22

K	X14
Ø20mm	



Cover the visible hole with a cap