




# Solar Street Light Remote Control User Menu



# Solar Street Light Instruction


## Installation Instructions:

- ① Please link the shell and light pole of the street light with nut which is installed on the shell with hex key.
- ② Please bore the hole into the wall.
- ③ Please tighten the nut with a hex wrench and secure it.



## Functions

- ☀ Please turn on the switch before installation and charging.
- ☀ Please choose a position without any shelter for enough sunshine and fully exposure.



Auto charge at daytime    By automatic timer turns the street light on at night and off in the morning.    No pedestrian at night, 30% brightness.    When a pedestrian into the induction area-100% brightness.

## Application:

Outdoor wall or pole in Plaza, Park, Garden, Courtyard, Street, Walkway, Pathway, Campus, Farm, Perimeter Security etc...