


## How to Adjust Door Hinges?

Find more detail about hinge adjusting on follow Video:  
<https://www.youtube.com/watch?v=56cqwMnKRz0>


### PIVOT-PRO side adjustment

Side adjustment of the door is made by using the indicated screw.



### PIVOT-PRO Depth Adjustment

Depth adjustment is made without loosening any screw. The door can be moved in or out by rotating the cam adjuster on the hinge arm.



### PIVOT-PRO Height Adjustment

By loosening the two fixing screws to allow the mounting plate to slide up or down the door can be adjusted vertically by 12mm. After retightening the screws, the Depth adjustment is done.

