

Activate your 5 year warranty



Electric blanket

IMPORTANT INSTRUCTIONS

DO NOT DESTROY

Warnings and Safeguards

Please read all instructions and product labels before using heated blanket. Failure to properly follow instructions may cause overheating, fire, or injury.

1. Do not use this heated blanket with an infant, a child, an incapacitated or immobile person, a paraplegic, a quadriplegic, a diabetic, one sensitive to heat such as a person with poor blood circulation, or anyone who cannot understand clearly the instructions and/or operate the controls.
2. Do not route electrical cords between the mattress and box spring. Do not allow the cords to be pinched.
3. Do not use with damaged cords. Damaged cords can lead to a fire. Do not tuck in, trap, fold, cross or pinch cords or controls between bed slats, mattress or springs, or against wall, footboards or bed frame.
4. Do not dry clean this heated product. Cleaning liquids may damage the insulation of the heating element. Improper laundering may cause problems with the heating wire which can lead to fire.
5. Do not tuck in, pinch, flex or expose the heating wire to rubbing. A damaged heating wire may result in possible overheating or fire. Do not tuck or wrap the heated blanket, supply cord or control in a sofa or other furniture. All portions of the heated blanket and controller should be visible at all times.
6. Turn off or unplug the control for the heated blanket when not using.
7. Wrapping the cord around the controller may damage the cord. Loop loosely when storing.
8. Controller is **NOT** waterproof. Do not immerse in water.
9. Keep the control away from drafty areas that may become damp or wet such as an open window.
10. Do not use pins; they may damage the electric wiring.
11. Be sure this blanket is used only on an AC supply current circuit of 110-120 volts. Do not use with an extension cord or power strip.
12. The product may experience increased heat in areas where heated blanket is bunched or folded while in use.


IMPORTANT INSTRUCTIONS

DO NOT DESTROY

Warnings and Safeguards continued

13. Keep all dogs, cats and other pets away from this heated blanket. This is an electrical appliance that they can damage or be injured by.
14. Do not use blanket on a waterbed, sofa, bunk bed or mechanically adjustable bed.
15. Do not use another electrical heating device in conjunction with your heated blanket, such as a heated mattress pad.
16. Use the proper size blanket for your bed. For example, use a Twin size heated blanket on a Twin size bed.
17. If the above instructions are not followed, the heated blanket will not operate properly.
18. Not for hotel, motel or other institutional use.
19. If your heated blanket is not functioning properly, please call our customer care team.

Heated Blanket Setup



1. Place the heated blanket on the bed with the label at the foot of the bed facing upward.
2. Connect the cord into the module at the bottom of the heat blanket until the plastic hinges CLICK into place. (see photos top right)


CAUTION: Cord must be COMPLETELY CONNECTED. A risk of fire could result from a loose connection.

3. Run the control cord on the floor under the bed. Do not sandwich cord between the mattress and box spring. Avoid any tangling or pinching.

4. Control Placement:

Dual controls for heated blanket-place one on each side of bed.

(Single control for heated blanket can be placed on either side of bed)



5. Plug the power cords into a 110-12 volt wall outlet.

CAUTION: Do not use with generator power or plug into an extension cord or power strip.

CAUTION: Do not plug power cord into the wall outlet until you have completely set up your heated blanket per the instructions. Disconnect power cord from wall before detaching control from heated blanket. Always make sure cords and controls are NOT trapped or pinched between bed slats, mattress, springs, against wall, foot board or bed frame, or between furniture, walls or chairs.

CAUTION: Do not attempt to force plug. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electrical shock, this plug is intended to fit only one way into an outlet. If the plug does not fit, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

Care and Cleaning of your Electric Blanket

We recommend washing before initial use.

Before Washing or Storing your Heated Product:

1. Disconnect power cord from wall BEFORE detaching control from the heated blanket.
2. Ensure that no cords are still connected and none of the wires have worn through the fabric.
3. Carefully follow all washing instructions or your heated blanket may shrink and possibly cause a fire hazard.

DO NOT submerge control in water.

DO NOT dry clean your heated blanket. Dry cleaning solvents may damage the wires.

DO NOT use bleach or cleaning fluids.

DO NOT iron your heated blanket.

DO NOT use mothballs or sprays of any kind.

DO NOT reconnect the heated blanket or use it until COMPLETELY dry.

DO NOT wash or put into water the power cord or any of the product's cords.

DO NOT use analgesic cream in combination with your heated blanket.

Taking care of your heated blanket is easy and safe as long as you follow a few simple steps.

Machine Washing

1. Presoak the blanket for 15 minutes in mild soap and cold water.
2. Wash in mild soap and cold water on the "delicate" or "gentle" cycle in the washer for two minutes. Remember, do not use bleach.
3. Rinse in fresh, cold water.
4. Spin dry in the washing machine. Then gently stretch to its original size.

Machine Drying

Caution: Do not use commercial dryers or the dryers at your local laundromat. They get too hot and would damage the wiring of the heated blanket.

1. Preheat the dryer on the "low" temperature setting for 2 minutes.
2. Place blanket into the dryer and tumble dry for 10 minutes at a low temperature.
3. Remove the blanket while it is still damp and gently stretch it to its original size.
4. Drape the heated product over a clothesline or a shower rod. DO NOT use clothespins.
5. Heated blanket must be COMPLETELY dry before connecting the power plug or control plug.

Hand Drying

1. Gently stretch the blanket back to its original size.
2. Drape the heated product over a clothesline or hang over a shower rod. DO NOT use clothespins.
3. Heated blanket must be COMPLETELY dry before reconnecting the power plug or control plug.

Frequently Asked Questions about your Heated Blanket

Q: Who should NOT use the heated blanket?

A: An Infant

A child

An incapacitated or immobile person

A paraplegic

A quadriplegic

A diabetic

Anyone insensitive to heat such as a person with poor blood circulation

Anyone who cannot clearly understand the instructions and/or operate the controls

Q: What do the Underwriters Laboratories (ETL) labels mean? What does the label mean about the safety of Products heated blanket?

A: Intertek Testing Services (ETL) is a certified, independent testing organization that test products in accordance with UL/cUL safety standards and issues the ETL label for those products that meet the relevant UL/cUL standards. All products are tested to UL/cUL standards and bear the ETL/cETL label to indicate that the product meets or exceeds UL/cUL or ETL/cETL safety standards for heated products.

Q: I have heard that some heated products have EMFs.

A: EMF stands for Electromagnetic Field. This is an electrical field that surrounds any wire that has current flowing along its length. Although several studies have been conducted to evaluate the impact, EMFs have not been proven to be harmful.

Q: What do I do if my pet chews the cord, I lose my controller or the controller does not operate properly?

A: Please stop using the heated product immediately. Call our Consumer Service and ask for instructions.

Q: My controller feels warm to the touch. Is this a problem?

A: No. The control will feel warm to the touch when operating properly.

Frequently Asked Questions about your Heated Blanket

Q: My heated blanket doesn't heat properly.

A: Your heated blanket is not a heating pad. It will not feel hot to the touch when laid out flat in a normal manner. Try the following fold test to see if it is operating properly:

1. Fold the heated blanket 3 times over.
2. Make sure the control cord is connected to the module and then plug the power cord into an outlet.
3. Turn on your heated product, then turn the control to the highest setting and wait 5 to 7 minutes.
4. Put your hand between the folds and you should feel the blanket warming up.

CAUTION: DO NOT continue the test for more than 7 minutes. DO NOT attempt to make any internal adjustments to this appliance. If you tried all of the solutions above and the heated blanket still does not work, stop using it immediately, disconnect the power cord and contact us.

Using your controller



1. Plug power cord into 110-120 volt wall outlet. Do not plug into power strip or extension cord.
2. Power on blanket by pressing center "On/Off" button.
3. Set your desired temperature and timer settings by selecting the "+" or "-" buttons.
4. Your blanket will take 30 minutes to reach your selected temperature setting.
5. The screen will dim after 40 seconds of inactivity. Press one of the "+" or "-" buttons to activate screen or change settings.

Control Features:

1. Ten temperature settings for targeted control for your heat levels.
2. Programmable timer with options to set between 1 and 12 hours.
3. Memory function-your previous temperature and timer selection will be set for next use, no programming necessary.
4. Quick heat function-temperature will quickly rise to the high heat and then lower to selected heat setting within 30 minutes. This is perfect for preheating your bed.
5. Five year warranty.

Register Your New Electric Product

Thank you for your recent electric product purchase!
Please take a few minutes to register your new product
for our 5-year warranty

Your registration must be received within 30 days of purchase and a valid customer order number is required. After you submit your registration, you'll receive email confirmation that your form has been received. The email will serve as your record that your warranty has been activated.

If you have questions, please reach out to us