

正面

4 Person Family Camping Tent Instruction Manual

Before you begin

Read all instructions before set up.
Select a level site clear of rocks,branches, and other hard or sharp objects to install your tent.

Warning: Keep clear of overhead power lines.
Do not set up your tent under trees because of potential lighting strikes or falling tree limbs in inclement weather.
Secure with all stakes and guy lines provided to prevent property damage or personal injury.


For best results in windy conditions, position narrow end of tent into the wind.
Do not drop tent or pole bag on its end.
Do not bounce tent bag on its end to get the tent out, as these actions may damage the frame.

Although it is possible to pitch this tent alone, it is faster/easier to with two people.
Under no circumstances should this product be used to cover automobiles,marine products or similar items.


Never let tent poles snap together as this can damage the pole end.
Caution: Avoid pinch points when opening and closing tent frame.

Component List:

Component	Quantity
① Tent Poles	2
② Fly Pole	1
③ Ground Stakes	14
④ Tent Body	1
⑤ Rain Fly	1
⑥ Guy Lines	9
⑦ Sunshade curtain	1
⑧ Support rod group	2
⑨ Dry hanging net	1
⑩ Bag of stakes	1
⑪ Bag of Poles	1
⑫ Storage Bag	1



How to Set Up A Tent



WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.

The tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

Never use any fuel burning oxygen consuming devices or any devices that produce any fumes, including stoves, lanterns, candles, hibachis or heaters in or around your tent. This could result in carbon monoxide poisoning, injury or death.

Your failure to follow these warnings could cause death, serious injury or permanent disability to you or others.

Made in China


10 mm
210 mm

反面

Made in China

Happy Camper Experience!

HOWALK



Item Name: Camping Tent

poisoning, injury and/or death.

around your tent. This could result in carbon mono

stoves, lanterns, candles, hibachis or heaters in or

or any devices that produce any fumes, including

● Never use any fuel burning oxygen consuming dev

ineffective.

● The application of any foreign substance to the ten

fabric may render the flame-resistant properties

contact with any flame source.

CPAI-84. The fabric may burn if left in continuous

● This tent meets the flammability requirements of

TENT FABRIC.

SOURCES AWAY FROM THIS

KEEP ALL FLAME AND HEAT

WARNING

Item Name: Camping Tent

10 mm
210 mm

290 mm

深圳市五洲行户外用品有限公司
Abris Outdoor Co.,Ltd.

物料名称	普通布标/合成胶带/29*21cm/A4 /单黑双面印/四人帐篷加天幕 /说明书布标	
适用产品	120893 四人帐篷加天幕 客户2006	
文件编号	WI-RD-3221	A. 0
物料编号	7120893	
输出日期	2024/01/04	16:08
业务员	郑明义	
制图	祝桂裕/电话17788771663	
确认		
批准		

工艺要求

印刷颜色: ■ 黑色

印刷尺寸: 290mm*210mm

布料: 合成胶带

位置: 居中双面印刷

注意事项: 印刷不可重影、重印、刮花、移位、漏印、错印、不清晰、未干透、印刷透底等不良现象, 印刷内容与图纸相符

T0: 存档1份, 品质部2份, 其它人员请查阅电子文档
电子档存放位置: \\192.168.1.20\资料区\04平面资料