






ASSEMBLY INSTRUCTIONS



①  x2	②  x1	③  x1
④  x2	⑤  x6	


A  x2	B  x2	C  x6	D  6*35mm x10
E  6*16mm x12	F  6*10mm x16	G  6*18mm x22	H  M5 x1

STEP 1




Cx6

STEP 2



Dx10
Gx10
Hx1


STEP 3



Tighten the screw to 80%.

Ax2
Fx8
Hx1


STEP 4



Tighten the screw to 80%.

Bx2
Fx8
Hx1



STEP 5



Tighten all screws to 100%.

Ex12
Gx12
Hx1

STEP 6



the table is with adjustable feet, if the table is not stable, please adjust the feet.