




INSTALLATION

Product Manual




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer—could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.







Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.






Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 170  M5 x 42 mm	B x 170  Ø 15 x 10 mm	C x 50  M5 x 40 mm	D x 4  Ø 8 x 40 mm	E x 24  M3.5 x 12 mm
F x 145  M3.5 x 14 mm	G x 41  M3.5 x 14 mm	H x 8  M6 x 20 mm	I x 8  M6 x 30 mm	J x 19  M6 x 35 mm
K x 8  M6 x L15 mm	L x 6  64 mm	M x 12  M4 x 15 mm	N x 3  111 x 96 mm	O x 6  M4 x 20 mm
P x 18  35 x DW	Q x 16  Ø 5 mm	R x 4 	S x 12  Ø 1.5 x 15 mm	T x 12  Ø 15 x 10 mm
U x 2  Ø 8x60 mm  Ø 5x55 mm	V x 2 	x 2  #4		




⚠ WARNING





Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*






⚠ WARNING




Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*



ASSEMBLED BY 2 ADULTS




⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:






- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is a permanent label.
Do not remove!*





ASSEMBLED BY 2 ADULTS

1



Screw eccentric rod (A) onto plates 3 and 4.



2



Connect plates 6 and 7 to plates 3 and 4 using wooden dowel (D), then tighten by turning cam lock (B) clockwise.

3


C x 4
M5 x 40 mm



Secure plate 5 to plate 6 using screw (C).

4

A x 8




M5 x 42 mm



B x 8






Ø 15 x 10 mm





Screw eccentric rod (A) onto plates 3 and 4.
Connect plate 8 to plates 3, 4, and 5, then
tighten by turning cam lock (B) clockwise.



5




Screw eccentric rod (A) onto plates 9 and 10.
Connect plates 9 and 10 to plates 3, 4, and 5,
then tighten by turning cam lock (B) clockwise.



6


I x 8  M6 x 30 mm	K x 8  M6 x L15 mm	x 1  #4	
--	---	--	--



Secure plate 12 to plate 5 using screw (I) and (K).

7

J x 8  M6 x 35 mm	x 1  #4	
--	--	--





Secure plate 11 to plates 3 and 4 using screw (J).

8


F x 24



M3.5 x14 mm



Secure slide rail 18 to plates 11 and 12 using screw (F).





9



A x 12



B x 12




Screw eccentric rod (A) onto plate 2.
Connect plate 2 to plates 3, 4, 6, and 7, then
tighten by turning cam lock (B) clockwise.



10

A x 8




M5 x 42 mm



B x 8



Ø15 x 10 mm





Secure the screw (A) to Plate 1.
Connect plate 1 to plates 3, 4, and 5, then
tighten by turning cam lock (B) clockwise.




11

A x 10
M5 x 42 mm






Screw eccentric rod (A) onto plate 2.




12


A x 18
M5 x 42 mm



Screw eccentric rod (A) onto plates 21, 25, and 27.



x2






x2

13

B x 8



Ø 15 x 10 mm



x2




Connect plate 24 to plates 25 and 27 respectively, then tighten by turning cam lock (B) clockwise.

14

B x 10




Ø 15 x 10 mm






Connect plates 24, 25, 26, and 27 to plate 21, then tighten by turning cam lock (B) clockwise.

15


A x 20



M5 x 42 mm



Flip to the other side






Screw eccentric rod (A) onto **both sides of** plate 22.

16

B x 10



Ø 15 x 10 mm







Connect plate 22 to plates 24, 25, 26, and 27, then tighten by turning cam lock (B) clockwise.

17

B x 10






Ø 15 x 10 mm



Connect plates 24, 25, 26, and 27 to plate 22, then tighten by turning cam lock (B) clockwise.

18

A x 10
M5 x 42 mm






Screw eccentric rod (A) onto plate 23.

19

B x 10



Ø 15 x 10 mm





Connect plate 23 to plates 24, 25, 26, and 27, then tighten by turning cam lock (B) clockwise.

20

C x 14






M5 x 40 mm




Secure panel 30 to panel 29 using screw (C).

21



Screw eccentric rod (A) onto plate 29.






22


B x 10



Ø 15 x 10 mm



Connect plate 29 to plates 21, 22, 23, and 24, then tighten by turning cam lock (B) clockwise.





Need Two or More
People to Complete

23

G x 20




M3.5 x 14 mm



Secure panel 32 to the unit using screw (G).

24






Secure iron sheet (T) to plate 32 using screw (S).

25


B x 10



Ø 15 x 10 mm




Connect the two assembled components, then tighten by turning cam lock (B) clockwise.



Need Two or More
People to Complete

26

A x 8






M5 x 42 mm

B x 8





Ø 15 x 10 mm



Screw eccentric rod (A) onto plate 34. Connect plate 34 to plates 36 and 37, then tighten by turning cam lock (B) clockwise.

27




C x 8
M5 x 40 mm



Secure plate 35 to plates 37 and 36 using screw (C).

28


A x 14
M5 x 42 mm



Screw eccentric rod (A) onto plate 35.

29

A x 4




M5 x 42 mm



B x 4



Ø 15 x 10 mm




Screw eccentric rod (A) onto plate 34.
Connect plate 41 to plate 34, then tighten
by turning cam lock (B) clockwise.



30

A x 8








M5 x 42 mm


B x 8







Ø 15 x 10 mm



x2



x2



Screw eccentric rod (A) onto plates 39 and 40.
Connect plates 39 and 40 to plates 36 and 37, then tighten
by turning cam lock (B) clockwise.

31

H x 8



M6 x 20 mm

J x 4





M6 x 35 mm

x 1




#4



Secure plates 42 and 43 to plate 36 using screw (J) and (H).

32







Secure plates 44 and 45 to plate 34 using screw (J).

33

B x 14

 Ø 15 x 10 mm





Connect plate 35 to plate 30, then tighten by turning cam lock (B) clockwise.

34

G x 21





M3.5 x 14 mm



Secure plates 31 and 38 to the unit using screw (G).



35



Secure iron sheet (T) to plates 31 and 38 using screw (S).

36



C x 24
M5 x 40 mm





x6

Secure plates 15 and 16 to plate 14 using screw (C).
Insert plate 17 into the available slots.

37

A x 24  M5 x 42 mm	B x 24  Ø 15 x 10 mm	L x 6  64 mm	M x 12  M4 x 10 mm	
---	---	---	--	---

Screw eccentric rod (A) onto plate 13.
Connect plate 13 to plates 15 and 16, then
tighten by turning cam lock (B) clockwise.
Secure pull (L) to plate 13 using the screw (M).





38


E x 24





M3.5 x 12 mm



x6



Secure slide rail 18 to plates 15 and 16 using screw (E).
Install the drawers into the assembly.




39

Q x 16



Ø 5 mm



Insert pin (Q) into plates 21, 22, and 23.
Place the shelf plate 28 on pins.

40

F x 24







M3.5 x 14 mm

P x 12



35-DW



x2




Secure hinge (P) to plates 19 and 20 using screw (F).

41

F x 24



M3.5 x 14 mm





Secure plates 19 and 20 to plates 22 and 23 via hinges using screw (F).

42

F x 24



M3.5 x 14 mm



Secure plates 19 and 20 to plates 21 and 22 via hinges using screw (F).




43

F x 8



M3.5 x 14 mm

R x 4



Secure hook (R) to plates 19 and 20 using screw (F).

44

F x 12




M3.5 x 14 mm

P x 6



35-DW

N x 3





111 x 96 mm

O x 6



M4-20 mm



Secure hinge (P) to plate 33 using screw (F).
Secure handle (N) to panel 33 using screw (O).




x3

45

F x 24



M3.5 x 14 mm



Secure plate 33 to plates 42 and 43 via hinges using screw (F).

46

F x 2



M3.5 x 14 mm

U x 2






Ø8x60




Ø5x55


V x 2




1.





2.




3.





4.




Install the anti-tip device as shown in the figure.




If the door panels are not aligned, please adjust the screws on the hinges according to the illustration.





I




II




III





I




II




III



I



II



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.