



## PR39-ALL-BARS CEILING POT RACK

**Thank you for choosing Enclume!**

**Enclume racks are the ultimate quality, design, strength and function.**

**WARNING: READ ALL OF THE INSTRUCTIONS BEFORE ASSEMBLING AND USING YOUR RACK**



**If you need help, please call 1-877-ENCLUME**

**Enclume Design Products**

24 Colwell Street, Port Hadlock, WA 98339

Phone 360-385-6100 • Fax 360-385-6156

[www.enclume.com](http://www.enclume.com)

Enclosed you will find everything needed for the assembly and use of your storage rack. Two people make assembly and installation easier. The parts and hardware included are:

**Hardware included:**

- 4 – Ceiling Screw Hooks
- 4 – 2” ‘S’ Hooks
- 4 – 6” Chain lengths
- 2 – Toggle Kit

**Components included:**

- 1 – Rack Body
- 4 – Hanging Arms
- 12 – Straight Pot Hooks - WSPHS

**See reverse side for ASSEMBLY AND INSTALLATION INSTRUCTIONS**

# ASSEMBLY AND INSTALLATION INSTRUCTIONS

## Rack Assembly

- 1) Place the rack body on a firm, flat surface. Locate the hanging arms. At each long end of the rack body locate the two holes for connecting the hanging arms to the body.
- 2) Connect the lower ends of the hanging arms into the rack body by hooking these ends through the holes in the rack body.
- 3) With the hanging bars at right angles to the rack body, hold the rack to the ceiling and mark the four locations at the top four corners of the hanging bars where ceiling hooks will be inserted in the ceiling.
- 4) We recommend that you anchor your rack into the solid wood of ceiling joists or beams. Carefully measure the area where the rack is to be hung and install the ceiling screw hooks directly into the wood joists. If it is not convenient to hang your rack directly into wood joists you may use the included DRYWALL anchors enclosed with your rack. See Toggler® brand manufacturer recommendations for weight limits included in the instructions in the Toggler kit.
- 5) Using the four 'S' hooks provided, hang the rack from the four corners of the hanging arms. Hook one end of each of the 'S' hook over one of the corners of the arm and the other end over the ceiling hook above it. Repeat this process to connect the other hanging arm corners to the remaining open ceiling hooks.
- 6) Should you desire to lower your rack, included are four 6" chain lengths to insert between the 'S' hooks on the hanging arm corners and the ceiling hooks.



It is important that your rack is assembled correctly. If the unit is assembled or used incorrectly, it could become unstable and collapse, possibly causing injury.

**Limited Warranty:** This product is warranted to be free of material defects for a period of five years from the date of original purchase. The original purchaser's exclusive remedy is, at the company's option, the repair or replacement of the defective product. This remedy is subject to the following conditions: (1) receipt by Enclume, within the warranty period, of notice of a defect – together with evidence of original purchase, and (2) return of the defective product to Enclume Design Products, 24 Colwell St., Port Hadlock, WA 98339, *postage prepaid*, within 20 days following receipt of a return authorization number from the company. A return authorization number may be obtained by telephoning the company at the top of these instructions. **THE COMPANY MAKES NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, AND SPECIFICALLY MAKES NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FURTHER, ENCLUME DISCLAIMS ANY AND ALL INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE PURCHASE OR USE OF ENCLUME'S PRODUCTS.**